

# Smart Configurator for RX Plug-in in e<sup>2</sup> studio 2024-10

## Smart Configurator for RX V2.23.0

### Release Note

---

#### Introduction

Thank you for using the Smart Configurator for RX.

This document describes the restrictions and points for caution. Read this document before using the product.

#### Contents

|  |    |
|--|----|
| 1. Introduction.....   | 3  |
| 1.1 System requirements.....   | 3  |
| 1.1.1 Windows PC.....  | 3  |
| 1.1.2 Linux PC.....  | 3  |
| 1.1.3 Mac OS.....  | 3  |
| 1.1.4 Development Environments.....  | 3  |
| 2. Support List.....   | 4  |
| 2.1 Support Devices List.....  | 4  |
| 2.2 Support Components List.....   | 10 |
| 2.3 New support.....   | 16 |
| 2.3.1 Update BSP (Board Support Package) revision.....                             | 16 |
| 2.3.2 Update RX260, RX261 revision.....  | 16 |
| 2.3.3 Support GCC RX Toolchain for Smart Configurator standalone.....              | 16 |
| 2.3.4 Support CMake generation for Smart Configurator with Visual Studio Code..... | 17 |
| 2.3.5 Add WAIT_LOOP comment.....   | 18 |
| 2.3.6 Support encoder and hall sensor for Motor component.....                     | 18 |
| 2.3.7 Support magnet sensor for Motor component.....                               | 19 |
| 3. Changes.....  | 20 |
| 3.1 Correction of issues/limitations.....  | 20 |
| 3.1.1 Fixed I2C master mode with ACK/NACK interrupts.....                          | 20 |
| 3.1.2 Fixed Group Scan Mode S12AD with group priority control.....                 | 20 |
| 3.1.3 Fixed Continuous Scan Mode S12AD with channel 0.....                         | 20 |
| 3.1.4 Fixed Buses with 8-bit data width.....                                       | 20 |
| 3.1.5 Fixed Developer Assistance for I2C Master Mode.....                          | 20 |
| 3.2 Specification changes.....   | 21 |
| 3.2.1 Improve Clock warning icon.....  | 21 |
| 3.2.2 Improve Real Time Clock generated code.....                                  | 22 |
| 3.2.3 Improve application selection UI of RTOS.....                                | 23 |
| 3.2.4 Improve API name of Motor component.....                                     | 23 |

|        |  |    |
|--------|--|----|
| 4.     | List of RENESAS TOOL NEWS AND TECHNICAL UPDATE .....   | 24 |
| 5.     | Points for Limitation .....  | 30 |
| 5.1    | List of Limitation.....  | 30 |
| 5.2    | Details of Limitation .....  | 31 |
| 5.2.1  | Note on the general I/O port direction issue on MCU package view when using Port Component.... | 31 |
| 5.2.2  | Note on the resource tree in the FIT component GUI configuration .....                         | 31 |
| 5.2.3  | Note on address bus when using external bus .....  | 32 |
| 5.2.4  | Note on Port module combo box in ELC component when using Port component .....                 | 32 |
| 5.2.5  | Note on tab display on Mac OS.....   | 34 |
| 5.2.6  | Note on bus priority setting.....  | 34 |
| 5.2.7  | Note on RTC with main clock.....   | 35 |
| 6.     | Points for Caution .....   | 36 |
| 6.1    | List of Caution.....   | 36 |
| 6.2    | Details of Caution .....   | 38 |
| 6.2.1  | Note on configuring GPT interrupts.....  | 38 |
| 6.2.2  | Note on using only reception in SCI Clock Synchronous Mode.....                                | 39 |
| 6.2.3  | Note on using high transfer speed in SCIF Synchronous Mode .....                               | 39 |
| 6.2.4  | Note on device change functionality .....  | 40 |
| 6.2.5  | Note on using Smart Configurator for GCC project in e <sup>2</sup> studio 7.4.0.....           | 40 |
| 6.2.6  | Note on using Data Transfer Controller .....   | 40 |
| 6.2.7  | Note on Ports setting when using S12AD components .....  | 40 |
| 6.2.8  | Note on section build warning when using FIT components.....                                   | 40 |
| 6.2.9  | Note on C++ project support in CS+ .....   | 41 |
| 6.2.10 | Note on Installation directory.....  | 42 |
| 6.2.11 | Note on the build error of existing RTOS C++ project.....                                      | 42 |
| 6.2.12 | Note on the output of high impedance issue for TXDn pin .....                                  | 42 |
| 6.2.13 | Note on the include path update issue when renaming the component's configuration name.....    | 43 |
| 6.2.14 | Note on accessing "Release Notes" and "Tool News" URL from the help menu.....                  | 45 |
| 6.2.15 | Note on the IPCF file naming change for IAR project .....                                      | 45 |
| 6.2.16 | Note on using user code protection feature .....   | 45 |
| 6.2.17 | Note on code generation difference at Components tab and not at Components tab.....            | 46 |
|        | Revision History .....   | 47 |

## 1. Introduction

Smart Configurator is a utility for combining software to meet your needs. It supports the following three functions related to the embedding of Renesas drivers in your systems: importing middleware, generating driver code, and setting pins.

Smart Configurator for RX V2.23.0 is equivalent to Smart Configurator for RX plug-in in e<sup>2</sup> studio 2024-10.

### 1.1 System requirements

The operating environment is as follows.

#### 1.1.1 Windows PC

- System: x64/x86 based processor
  - Windows® 11
  - Windows® 10 (64-bit version)
- Memory capacity: We recommend 4 GB or more
- Capacity of hard disk: At least 300 MB of free space.
- Display: Graphics resolution should be at least 1024 x 768, and the mode should display at least 65,536 colors.
- Processor: 1 GHz or higher (must support hyper-threading, multi-core CPUs)

#### 1.1.2 Linux PC

From Smart Configurator for RX plug-in in e<sup>2</sup> studio 2023-01 onwards will be supported on Linux OS.

- System: x64 based processor, 2 GHz or faster (with multicore CPUs)
  - Ubuntu 22.04 LTS Desktop (64-bit version)
  - Ubuntu 20.04 LTS Desktop (64-bit version)
- Memory capacity: We recommend 2 GB or more.
- Capacity of hard disk: At least 2 GB of free space.

#### 1.1.3 Mac OS

From Smart Configurator for RX plug-in in e<sup>2</sup> studio 2024-04 onwards will be supported on Mac OS

- System: Apple ARM-based systems-on-a-chip (SoCs)
  - Mac OS 14 (Sonoma)
  - Mac OS 13 (Ventura)
- Memory capacity: We recommend 8 GB or more.
- Capacity of hard disk: At least 2 GB of free space.

#### 1.1.4 Development Environments

- Renesas electronics Compiler for RX [CC-RX] V3.01.00 or later
- GCC for Renesas 4.8.4.201902 or later
- IAR Embedded Workbench 4.12.1 or later
- Renesas electronics IDE CS+ for CC V8.12.00

## 2. Support List

### 2.1 Support Devices List

Below is a list of devices supported by the Smart Configurator for RX V2.23.0.

**Table 2-1 Support Devices**

| Group<br>(HW Manual number)      | PIN    | Device name   |
|----------------------------------|--------|---|
| RX110 Group<br>(R01UH0421EJ0120) | 36pin  | R5F5110HAxLM, R5F5110JAxLM, R5F51101AxLM, R5F51103AxLM  |
|                                  | 40pin  | R5F51101AxNF, R5F51103AxNF, R5F5110HAxNF, R5F5110JAxNF  |
|                                  | 48pin  | R5F51101AxNE, R5F51103AxNE, R5F51104AxNE, R5F51105AxNE,<br>R5F5110JAxNE, R5F51101AxFL, R5F51103AxFL, R5F51104AxFL,<br>R5F51105AxFL, R5F5110JAxFL  |
|                                  | 64pin  | R5F51101AxLF, R5F51103AxLF, R5F51104AxLF, R5F51105AxLF,<br>R5F5110JAxLF, R5F51101AxFK, R5F51103AxFK, R5F51104AxFK,<br>R5F51105AxFK, R5F5110JAxFK, R5F51101AxFM, R5F51103AxFM,<br>R5F51104AxFM, R5F51105AxFM, R5F5110JAxFM   |
| RX111 Group<br>(R01UH0365EJ0130) | 36pin  | R5F51111AxLM, R5F51113AxLM, R5F5111JAxLM  |
|                                  | 40pin  | R5F51111AxNF, R5F51113AxNF, R5F5111JAxNF  |
|                                  | 48pin  | R5F51111AxFL, R5F51113AxFL, R5F51114AxFL, R5F51115AxFL,<br>R5F51116AxFL, R5F51117AxFL, R5F51118AxFL, R5F5111JAxFL,<br>R5F51111AxNE, R5F51113AxNE, R5F51114AxNE, R5F51115AxNE,<br>R5F51116AxNE, R5F51117AxNE, R5F51118AxNE, R5F5111JAxNE   |
|                                  | 64pin  | R5F51111AxFM, R5F51113AxFM, R5F51114AxFM, R5F51115AxFM,<br>R5F51116AxFM, R5F51117AxFM, R5F51118AxFM, R5F5111JAxFM,<br>R5F51111AxFK, R5F51113AxFK, R5F51114AxFK, R5F51115AxFK,<br>R5F51116AxFK, R5F51117AxFK, R5F51118AxFK, R5F5111JAxFK,<br>R5F51111AxLF, R5F51113AxLF, R5F51114AxLF, R5F51115AxLF,<br>R5F51116AxLF, R5F51117AxLF, R5F51118AxLF, R5F5111JAxLF |
| RX113 Group<br>(R01UH0448EJ0110) | 64pin  | R5F51135AxFM, R5F51136AxFM, R5F51137AxFM, R5F51138AxFM  |
|                                  | 100pin | R5F51135AxLJ, R5F51136AxLJ, R5F51137AxLJ, R5F51138AxLJ,<br>R5F51135AxFP, R5F51136AxFP, R5F51137AxFP, R5F51138AxFP   |
| RX130 Group<br>(R01UH0560EJ0200) | 48pin  | R5F51303AxFL, R5F51305AxFL, R5F51303AxNE, R5F51305AxNE,<br>R5F51306AxNE, R5F51306AxFL, R5F51307AxNE, R5F51307AxFL,<br>R5F51308AxNE, R5F51308AxFL, R5F51306BxFL  |
|                                  | 64pin  | R5F51303AxFM, R5F51305AxFM, R5F51303AxFK, R5F51305AxFK,<br>R5F51306AxFK, R5F51306AxFM, R5F51307AxFK, R5F51307AxFM,<br>R5F51308AxFK, R5F51308AxFM R5F51308AxFK, R5F51308AxFM,<br>R5F51306BxFK, R5F51306BxFM  |
|                                  | 80pin  | R5F51303AxFN, R5F51305AxFN, R5F51306AxFN, R5F51306BxFN  |
|                                  | 100pin | R5F51305AxFP, R5F51306AxFP, R5F51307AxFP, R5F51308AxFP,<br>R5F51305BxFP, R5F51306BxFP   |
| RX13T Group<br>(R01UH0822EJ0100) | 32pin  | R5F513T3AxFJ, R5F513T5AxFJ, R5F513T3AxNH, R5F513T5AxNH  |
|                                  | 48pin  | R5F513T5AxFL, R5F513T3AxFL, R5F513T5AxNE, R5F513T3AxNE  |
| RX230 Group<br>(R01UH0496EJ0110) | 48pin  | R5F52305AxNE, R5F52306AxNE, R5F52305AxFL, R5F52306AxFL  |
|                                  | 64pin  | R5F52305AxND, R5F52306AxND, R5F52305AxFM, R5F52306AxFM,<br>R5F52305AxLF, R5F52306AxLF   |
|                                  | 100pin | R5F52305AxLA, R5F52306AxLA, R5F52305AxFP, R5F52306AxFP  |

Table 2-2 Support Devices

| Group<br>(HW Manual number)        | PIN        | Device name   |
|------------------------------------|------------|---|
| RX231 Group<br>(R01UH0496EJ0110)   | 48pin      | R5F52315AxNE, R5F52316AxNE, R5F52317AxNE, R5F52318AxNE,<br>R5F52315CxNE, R5F52316CxNE, R5F52317BxNE, R5F52318BxNE,<br>R5F52315AxFL, R5F52316AxFL, R5F52317AxFL, R5F52318AxFL,<br>R5F52315CxFL, R5F52316CxFL, R5F52317BxFL, R5F52318BxFL   |
|                                    | 64pin      | R5F52315AxND, R5F52316AxND, R5F52317AxND, R5F52318AxND,<br>R5F52315CxND, R5F52316CxND, R5F52317BxND, R5F52318BxND,<br>R5F52315AxFM, R5F52316AxFM, R5F52317AxFM, R5F52318AxFM,<br>R5F52315CxFM, R5F52316CxFM, R5F52317BxFM, R5F52318BxFM,<br>R5F52315CxLF, R5F52316CxLF  |
|                                    | 100pin     | R5F52315AxLA, R5F52316AxLA, R5F52317AxLA, R5F52318AxLA,<br>R5F52315CxLA, R5F52316CxLA, R5F52317BxLA, R5F52318BxLA,<br>R5F52315AxFP, R5F52316AxFP, R5F52317AxFP, R5F52318AxFP,<br>R5F52315CxFP, R5F52316CxFP, R5F52317BxFP, R5F52318BxFP   |
| RX23E-A Group<br>(R01UH0801EJ0100) | 40pin      | R5F523E5AxNF, R5F523E6AxNF, R5F523E5SxNF, R5F523E6SxNF  |
|                                    | 48pin      | R5F523E5AxFL, R5F523E6AxFL, R5F523E5SxFL, R5F523E6SxFL  |
| RX23T Group<br>(R01UH0520EJ0110)   | 48pin      | R5F523T3AxFL, R5F523T5AxFL  |
|                                    | 52pin      | R5F523T5AxFD, R5F523T3AxFD  |
|                                    | 64pin      | R5F523T5AxFM, R5F523T3AxFM  |
| RX23W Group<br>(R01UH0823EJ0100)   | 56pin      | R5F523W8BxNG, R5F523W8AxNG, R5F523W7BxNG, R5F523W7AxNG  |
|                                    | 83pin      | R5F523W8CxLN, R5F523W8DxLN  |
|                                    | 85pin      | R5F523W7AxBL, R5F523W8AxBL, R5F523W8BxBL, R5F523W7BxBL  |
| RX24T Group<br>(R01UH0576EJ0200)   | 64pin      | R5F524TAxFM, R5F524T8AxFM, R5F524TAxFK, R5F524T8AxFK  |
|                                    | 80pin      | R5F524TAxFF, R5F524T8AxFF, R5F524TAxFN, R5F524T8AxFN  |
|                                    | 100pin     | R5F524TCxFP, R5F524T8AxFP, R5F524TBxFP, R5F524TEAxFP,<br>R5F524TAxFP  |
| RX24U Group<br>(R01UH0658EJ0100)   | 100pin     | R5F524UEAxFP, R5F524UCxFP, R5F524UBxFP  |
|                                    | 144pin     | R5F524UEAxFB, R5F524UBxFB, R5F524UCxFB  |
| RX64M Group<br>(R01UH0377EJ0110)   | 100pin     | R5F564MFCxFP, R5F564MFCxLJ, R5F564MFDxFP, R5F564MFDxLJ,<br>R5F564MGCxFP, R5F564MGCxLJ, R5F564MGDxFP, R5F564MGDxLJ,<br>R5F564MJCxFP, R5F564MJCxLJ, R5F564MJDxFP, R5F564MJDxLJ,<br>R5F564MLCxFP, R5F564MLCxLJ, R5F564MLDxFP, R5F564MLDxLJ   |
|                                    | 144/145pin | R5F564MFCxFB, R5F564MFCxLK, R5F564MFDxFB, R5F564MFDxLK,<br>R5F564MGCxFB, R5F564MGCxLK, R5F564MGDxFB, R5F564MGDxLK,<br>R5F564MJCxFB, R5F564MJCxLK, R5F564MJDxFB, R5F564MJDxLK,<br>R5F564MLCxFB, R5F564MLCxLK, R5F564MLDxFB, R5F564MLDxLK   |
|                                    | 176/177pin | R5F564MFDxFC, R5F564MFDxBG, R5F564MFDxLC, R5F564MFCxFC,<br>R5F564MFCxBG, R5F564MFCxLC, R5F564MGDxFC, R5F564MGDxBG,<br>R5F564MGDxLC, R5F564MGCxFC, R5F564MGCxBG, R5F564MGCxLC,<br>R5F564MJDxFC, R5F564MJDxBG, R5F564MJDxLC, R5F564MJCxFC,<br>R5F564MJCxBG, R5F564MJCxLC, R5F564MLDxFC, R5F564MLDxBG,<br>R5F564MLDxLC, R5F564MLCxFC, R5F564MLCxBG, R5F564MLCxLC |

Table 2-3 Support Devices

| Group<br>(HW Manual number)      | PIN            | Device name   |
|----------------------------------|----------------|---|
| RX65N Group<br>(R01UH0590EJ0210) | 100pin         | R5F565N9AxLJ, R5F565N9BxLJ, R5F565N9ExLJ, R5F565N9FxLJ,<br>R5F565N7AxLJ, R5F565N7BxLJ, R5F565N7ExLJ, R5F565N7FxLJ,<br>R5F565N4AxLJ, R5F565N4BxLJ, R5F565N4ExLJ, R5F565N4FxLJ,<br>R5F565N9AxFP, R5F565N9BxFP, R5F565N9ExFP, R5F565N9FxFP,<br>R5F565N7AxFP, R5F565N7BxFP, R5F565N7ExFP, R5F565N7FxFP,<br>R5F565N4AxFP, R5F565N4BxFP, R5F565N4ExFP, R5F565N4FxFP,<br>R5F565NCHxLJ, R5F565NCDxLJ, R5F565NEHxLJ, R5F565NEDxLJ,<br>R5F565NCHxFP, R5F565NCDxFP, R5F565NEHxFP, R5F565NEDxFP |
|                                  | 144/145<br>pin | R5F565N9AxFB, R5F565N9BxFB, R5F565N9ExFB, R5F565N9FxFB,<br>R5F565N7AxFB, R5F565N7BxFB, R5F565N7ExFB, R5F565N7FxFB,<br>R5F565N4AxFB, R5F565N4BxFB, R5F565N4ExFB, R5F565N4FxFB,<br>R5F565NCHxFB, R5F565NCDxFB, R5F565NEHxFB, R5F565NEDxFB,<br>R5F565N9AxLK, R5F565N9BxLK, R5F565N9ExLK, R5F565N9FxLK,<br>R5F565N7AxLK, R5F565N7BxLK, R5F565N7ExLK, R5F565N7FxLK,<br>R5F565N4AxLK, R5F565N4BxLK, R5F565N4ExLK, R5F565N4FxLK,<br>R5F565NCHxLK, R5F565NCDxLK, R5F565NEHxLK, R5F565NEDxLK |
|                                  | 176/177<br>pin | R5F565NCHxBG, R5F565NCDxBG, R5F565NEHxBG, R5F565NEDxBG,<br>R5F565NCHxFC, R5F565NCDxFC, R5F565NEHxFC, R5F565NEDxFC,<br>R5F565NCHxLC, R5F565NCDxLC, R5F565NEHxLC, R5F565NEDxLC  |
| RX651 Group<br>(R01UH0590EJ0210) | 64pin          | R5F5651CHxFM, R5F56514FxFM, R5F5651EHxFM, R5F5651CDxFM,<br>R5F56514FxBP, R5F56514BxFM, R5F56519FxBP, R5F5651CDxBP,<br>R5F5651EDxBP, R5F5651EDxFM, R5F56517BxBP, R5F5651EHxBP,<br>R5F56519BxBP, R5F56517FxBP, R5F5651CHxBP, R5F56519FxFM,<br>R5F56517BxFM, R5F56514BxBP, R5F56519BxFM, R5F56517FxFM  |
|                                  | 100pin         | R5F56519AxLJ, R5F56519BxLJ, R5F56519ExLJ, R5F56519FxLJ,<br>R5F56517AxLJ, R5F56517BxLJ, R5F56517ExLJ, R5F56517FxLJ,<br>R5F56514AxLJ, R5F56514BxLJ, R5F56514ExLJ, R5F56514FxLJ,<br>R5F56519AxFP, R5F56519BxFP, R5F56519ExFP, R5F56519FxFP,<br>R5F56517AxFP, R5F56517BxFP, R5F56517ExFP, R5F56517FxFP,<br>R5F56514AxFP, R5F56514BxFP, R5F56514ExFP, R5F56514FxFP   |
|                                  | 144/145<br>pin | R5F56519AxFB, R5F56519BxFB, R5F56519ExFB, R5F56519FxFB,<br>R5F56517AxFB, R5F56517BxFB, R5F56517ExFB, R5F56517FxFB,<br>R5F56514AxFB, R5F56514BxFB, R5F56514ExFB, R5F56514FxFB,<br>R5F5651CDxFB, R5F5651CHxFB, R5F5651EDxFB, R5F5651EHxFB,<br>R5F56519AxLK, R5F56519BxLK, R5F56519ExLK, R5F56519FxLK,<br>R5F56517AxLK, R5F56517BxLK, R5F56517ExLK, R5F56517FxLK,<br>R5F56514AxLK, R5F56514BxLK, R5F56514ExLK, R5F56514FxLK,<br>R5F5651CDxLK, R5F5651CHxLK, R5F5651EDxLK, R5F5651EHxLK |
|                                  | 176/177<br>pin | R5F5651CDxBG, R5F5651CDxFC, R5F5651CHxBG, R5F5651CHxFC,<br>R5F5651EDxBG, R5F5651EDxFC, R5F5651EHxBG, R5F5651EHxFC,<br>R5F5651CDxLC, R5F5651CHxLC, R5F5651EDxLC, R5F5651EHxLC  |
| RX66N Group<br>(R01UH0825EJ0100) | 100pin         | R5F566NNDxFP, R5F566NNHxFP, R5F566NDDxFP, R5F566NDHxFP  |
|                                  | 144pin         | R5F566NNDxFB, R5F566NNHxFB, R5F566NDDxFB, R5F566NDHxFB  |
|                                  | 145pin         | R5F566NNDxLK, R5F566NNHxLK, R5F566NDDxLK, R5F566NDHxLK  |
|                                  | 176pin         | R5F566NNDxFC, R5F566NNHxFC, R5F566NDDxFC, R5F566NDHxFC,<br>R5F566NNDxBG, R5F566NNHxBG, R5F566NDDxBG, R5F566NDHxBG   |
|                                  | 244pin         | R5F566NNDxBD, R5F566NNHxBD, R5F566NDDxBD, R5F566NDHxBD  |

Table 2-4 Support Devices

| Group<br>(HW Manual number)      | PIN        | Device name   |
|----------------------------------|------------|---|
| RX66T Group<br>(R01UH0749EJ0120) | 48pin      | R5F566TABxFL, R5F566TAFxFL, R5F566TEBxFL, R5F566TEFxFL  |
|                                  | 64pin      | R5F566TAAxFM, R5F566TAEExFM, R5F566TEAxFM, R5F566TEExFM   |
|                                  | 80pin      | R5F566TAAxFF, R5F566TAEExFF, R5F566TEAxFF, R5F566TEExFF,<br>R5F566TAAxFN, R5F566TAEExFN, R5F566TEAxFN, R5F566TEExFN   |
|                                  | 100pin     | R5F566TKCxFP, R5F566TAEExFP, R5F566TFFxFP, R5F566TFCxFP,<br>R5F566TFExFP, R5F566TFBxFP, R5F566TFAxFP, R5F566TABxFP,<br>R5F566TAFxFP, R5F566TEFxFP, R5F566TKFxFP, R5F566TKGxFP,<br>R5F566TKAxFP, R5F566TKEExFP, R5F566TKBxFP, R5F566TEBxFP,<br>R5F566TEExFP, R5F566TEAxFP, R5F566TAAxFP, R5F566TFGxFP  |
|                                  | 112pin     | R5F566TAAxFH, R5F566TAEExFH, R5F566TEExFH, R5F566TEAxFH   |
|                                  | 144pin     | R5F566TKCxFB, R5F566TFGxFB, R5F566TFCxFB, R5F566TKGxFB  |
| RX71M Group<br>(R01UH0493EJ0110) | 100pin     | R5F571MLCxFP, R5F571MLDxFP, R5F571MLGxFP, R5F571MLHxFP,<br>R5F571MJCxFP, R5F571MJDxFP, R5F571MJGxFP, R5F571MJHxFP,<br>R5F571MGCxFP, R5F571MGDxFP, R5F571MFGxFP, R5F571MGHxFP,<br>R5F571MFCxFP, R5F571MFDxFP, R5F571MFGxFP, R5F571MFHxFP,<br>R5F571MLCxLJ, R5F571MLDxLJ, R5F571MLGxLJ, R5F571MLHxLJ,<br>R5F571MJCxLJ, R5F571MJDxLJ, R5F571MJGxLJ, R5F571MJHxLJ,<br>R5F571MGCxLJ, R5F571MGDxLJ, R5F571MGGxLJ, R5F571MGHxLJ,<br>R5F571MFCxLJ, R5F571MFDxLJ, R5F571MFGxLJ, R5F571MFHxLJ   |
|                                  | 144/145pin | R5F571MLCxLK, R5F571MLDxLK, R5F571MLGxLK, R5F571MLHxLK,<br>R5F571MJCxLK, R5F571MJDxLK, R5F571MJGxLK, R5F571MJHxLK,<br>R5F571MGCxLK, R5F571MGDxLK, R5F571MGGxLK, R5F571MGHxLK,<br>R5F571MFCxLK, R5F571MFDxLK, R5F571MFGxLK, R5F571MFHxLK,<br>R5F571MLCxLB, R5F571MLDxLB, R5F571MLGxLB, R5F571MLHxLB,<br>R5F571MJCxLB, R5F571MJDxLB, R5F571MJGxLB, R5F571MJHxLB,<br>R5F571MGCxLB, R5F571MGDxLB, R5F571MGGxLB, R5F571MGHxLB,<br>R5F571MFCxLB, R5F571MFDxLB, R5F571MFGxLB, R5F571MFHxLB   |
|                                  | 176/177pin | R5F571MLCxFC, R5F571MLDxFC, R5F571MLGxFC, R5F571MLHxFC,<br>R5F571MJCxFC, R5F571MJDxFC, R5F571MJGxFC, R5F571MJHxFC,<br>R5F571MGCxFC, R5F571MGDxFC, R5F571MGGxFC, R5F571MGHxFC,<br>R5F571MFCxFC, R5F571MFDxFC, R5F571MFGxFC, R5F571MFHxFC,<br>R5F571MLCxLC, R5F571MLDxLC, R5F571MLGxLC, R5F571MLHxLC,<br>R5F571MJCxLC, R5F571MJDxLC, R5F571MJGxLC, R5F571MJHxLC,<br>R5F571MGCxLC, R5F571MGDxLC, R5F571MGGxLC, R5F571MGHxLC,<br>R5F571MFCxLC, R5F571MFDxLC, R5F571MFGxLC, R5F571MFHxLC,<br>R5F571MLCxBG, R5F571MLDxBG, R5F571MLGxBG, R5F571MLHxBG,<br>R5F571MJCxBG, R5F571MJDxBG, R5F571MJGxBG, R5F571MJHxBG,<br>R5F571MGCxBG, R5F571MGDxBG, R5F571MGGxBG, R5F571MGHxBG,<br>R5F571MFCxBG, R5F571MFDxBG, R5F571MFGxBG, R5F571MFHxBG |
| RX72M Group<br>(R01UH0804EJ0110) | 100pin     | R5F572MDDxFP, R5F572MDHxFP, R5F572MNDxFP, R5F572MNHxFP  |
|                                  | 144pin     | R5F572MDDxFB, R5F572MDHxFB, R5F572MNDxFB, R5F572MNHxFB  |
|                                  | 176pin     | R5F572MNHxFC, R5F572MDDxBG, R5F572MNDxFC, R5F572MDHxBG,<br>R5F572MDDxFC, R5F572MNHxBG, R5F572MNDxBG, R5F572MDHxFC   |
|                                  | 224pin     | R5F572MDDxBD, R5F572MDHxBD, R5F572MNHxBD, R5F572MNDxBD  |

Table 2-5 Support Devices

| Group<br>(HW Manual number)      | PIN    | Device name  |
|----------------------------------|--------|--|
| RX72N Group<br>(R01UH0824EJ0100) | 100pin | R5F572NNDxFP, R5F572NNHxFP, R5F572NDDxFP, R5F572NDHxFP   |
|                                  | 144pin | R5F572NNDxFB, R5F572NNHxFB, R5F572NDDxFB, R5F572NDHxFB   |
|                                  | 145pin | R5F572NNDxLK, R5F572NNHxLK, R5F572NDDxLK, R5F572NDHxLK   |
|                                  | 176pin | R5F572NNDxFC, R5F572NNHxFC, R5F572NDDxFC, R5F572NDHxFC,<br>R5F572NNDxBG, R5F572NNHxBG, R5F572NDDxBG, R5F572NDHxBG  |
|                                  | 224pin | R5F572NNDxBD, R5F572NNHxBD, R5F572NDDxBD, R5F572NDHxBD   |
| RX72T Group<br>(R01UH0803EJ0100) | 100pin | R5F572TKExFP, R5F572TFFxFP, R5F572TKFxFP, R5F572TFGxFP,<br>R5F572TKCxFP, R5F572TFBxFP, R5F572TFExFP, R5F572TFCxFP,<br>R5F572TFAxFP, R5F572TKAxFP, R5F572TKBxFP, R5F572TKGxFP   |
|                                  | 144pin | R5F572TKGxFB, R5F572TKCxFB, R5F572TFGxFB, R5F572TFCxFB   |
| RX671 Group<br>(R01UH0899EJ0100) | 48pin  | R5F5671EHxNE, R5F5671EDxNE, R5F5671CHxNE, R5F5671CDxNE,<br>R5F56719HxNE, R5F56719DxNE  |
|                                  | 64pin  | R5F5671EHxFM, R5F5671EDxFM, R5F5671CHxFM, R5F5671CDxFM,<br>R5F56719HxFM, R5F56719DxFM, R5F5671EHxBP, R5F5671EDxBP,<br>R5F5671CHxBP, R5F5671CDxBP, R5F56719HxBP, R5F56719DxBP   |
|                                  | 100pin | R5F5671EHxFP, R5F5671EDxFP, R5F5671CHxFP, R5F5671CDxFP,<br>R5F56719HxFP, R5F56719DxFP, R5F5671EHxLJ, R5F5671EDxLJ,<br>R5F5671CHxLJ, R5F5671CDxLJ, R5F56719HxLJ, R5F56719DxLJ   |
|                                  | 144pin | R5F5671EHxFB, R5F5671EDxFB, R5F5671CHxFB, R5F5671CDxFB,<br>R5F56719HxFB, R5F56719DxFB  |
|                                  | 145pin | R5F5671EHxLE, R5F5671EDxLE, R5F5671CHxLE, R5F5671CDxLE,<br>R5F56719HxLE, R5F56719DxLE, R5F5671EHxLK, R5F5671EDxLK,<br>R5F5671CHxLK, R5F5671CDxLK, R5F56719HxLK, R5F56719DxLK   |
| RX140 Group<br>(R01UH0905EJ0110) | 32pin  | R5F51403AxFJ, R5F51403AxNH   |
|                                  | 48pin  | R5F51403AxFL, R5F51403AxNE, R5F51405AxFL, R5F51405AxNE,<br>R5F51405BxFL, R5F51405BxNE, R5F51406AxFL, R5F51406AxNE,<br>R5F51406BxFL, R5F51406BxNE   |
|                                  | 64pin  | R5F51403AxFK, R5F51403AxFM, R5F51405AxFK, R5F51405AxFM,<br>R5F51405BxFK, R5F51405BxFM, R5F51406AxFK, R5F51406AxFM,<br>R5F51406BxFK, R5F51406BxFM   |
|                                  | 80pin  | R5F51405AxFN, R5F51405BxFN, R5F51406AxFN, R5F51406BxFN   |
| RX660 Group<br>(R01UH0937EJ0100) | 48pin  | R5F56609AxFL, R5F56609BxFL, R5F56604AxFL, R5F56604BxFL   |
|                                  | 64pin  | R5F56609AxFM, R5F56609BxFM, R5F56609CxFM, R5F56609DxFM<br>R5F56604AxFM, R5F56604BxFM, R5F56604CxFM, R5F56604DxFM   |
|                                  | 80pin  | R5F56609AxFN, R5F56609BxFN, R5F56609CxFN, R5F56609DxFN<br>R5F56604AxFN, R5F56604BxFN, R5F56604CxFN, R5F56604DxFN   |
|                                  | 100pin | R5F56609AxFP, R5F56609BxFP, R5F56609CxFP, R5F56609DxFP<br>R5F56609ExFP, R5F56609FxFP, R5F56609GxFP, R5F56609HxFP<br>R5F56604AxFP, R5F56604BxFP, R5F56604CxFP, R5F56604DxFP<br>R5F56604ExFP, R5F56604FxFP, R5F56604GxFP, R5F56604HxFP |
|                                  | 144pin | R5F56609AxFB, R5F56609BxFB, R5F56609CxFB, R5F56609DxFB<br>R5F56609ExFB, R5F56609FxFB, R5F56609GxFB, R5F56609HxFB<br>R5F56604AxFB, R5F56604BxFB, R5F56604CxFB, R5F56604DxFB<br>R5F56604ExFB, R5F56604FxFB, R5F56604GxFB, R5F56604HxFB |



Table 2-6 Support Devices

| Group<br>(HW Manual number)        | PIN    | Device name   |
|------------------------------------|--------|---|
| RX23E-B Group<br>(R01UH0972EJ0080) | 40pin  | R5F523E5BxNF, R5F523E5KxNF, R5F523E5MxNF, R5F523E6BxNF<br>R5F523E6KxNF, R5F523E6MxNF  |
|                                    | 48pin  | R5F523E5BxFL, R5F523E5MxFL, R5F523E6BxFL, R5F523E6MxFL  |
|                                    | 64pin  | R5F523E5BxFM, R5F523E5KxFM, R5F523E5MxFM, R5F523E6BxFM,<br>R5F523E6KxFM, R5F523E6MxFM   |
|                                    | 80pin  | R5F523E5JxFN, R5F523E5NxFN, R5F523E6JxFN, R5F523E6NxFN  |
|                                    | 100pin | R5F523E5LxBS, R5F523E5LxFP, R5F523E5NxBS, R5F523E5NxFP,<br>R5F523E6LxBS, R5F523E6LxFP, R5F523E6NxBS, R5F523E6NxFP   |
| RX26T Group<br>(R01UH0979EJ0101)   | 48pin  | R5F526T9AxFL, R5F526T9AxNE, R5F526T9BxFL, R5F526T9BxNE,<br>R5F526TBxFL, R5F526TBxNE, R5F526TBBxFL, R5F526TBBxNE,<br>R5F526TBCxFL, R5F526TBCxNE, R5F526TBDxFL, R5F526TBDxNE,<br>R5F526TFxFL, R5F526TFxNE, R5F526TFBxFL, R5F526TFBxNE,<br>R5F526TFCxFL, R5F526TFCxNE, R5F526TFDxFL, R5F526TFDxNE,<br>R5F526T8AxFL, R5F526TAAxFL, R5F526TACxFL |
|                                    | 64pin  | R5F526T9AxFM, R5F526T9AxND, R5F526T9BxFM, R5F526T9BxND,<br>R5F526TBxFM, R5F526TBxND, R5F526TBBxFM, R5F526TBBxND,<br>R5F526TBCxFM, R5F526TBCxND, R5F526TBDxFM, R5F526TBDxND,<br>R5F526TFxFM, R5F526TFxND, R5F526TFBxFM, R5F526TFBxND,<br>R5F526TFCxFM, R5F526TFCxND, R5F526TFDxFM, R5F526TFDxND,<br>R5F526T8AxFM, R5F526TAAxFM, R5F526TACxFM |
|                                    | 80pin  | R5F526T9AxFN, R5F526T9BxFN, R5F526TBxFN, R5F526TBBxFN,<br>R5F526TBCxFN, R5F526TBDxFN, R5F526TFxFN, R5F526TFBxFN,<br>R5F526TFCxFN, R5F526TFDxFN  |
|                                    | 100pin | R5F526T9AxFP, R5F526T9BxFP, R5F526TBxFP, R5F526TBBxFP,<br>R5F526TBCxFP, R5F526TBDxFP, R5F526TFxFP, R5F526TFBxFP,<br>R5F526TFCxFP, R5F526TFDxFP  |
|                                    |        |   |
| RX260 Group<br>(R01UH1045EJ0100)   | 48pin  | R5F52606AxFL, R5F52606AxNE, R5F52607AxFL, R5F52607AxNE,<br>R5F52608AxFL, R5F52608AxNE   |
|                                    | 64pin  | R5F52606AxFM, R5F52607AxFM, R5F52608AxFM  |
|                                    | 80pin  | R5F52606AxFN, R5F52607AxFN, R5F52608AxFN  |
|                                    | 100pin | R5F52606AxFP, R5F52607AxFP, R5F52608AxFP  |
| RX261 Group<br>(R01UH1045EJ0100)   | 48pin  | R5F52616AxFL, R5F52616AxNE, R5F52616BxFL, R5F52616BxNE,<br>R5F52617AxFL, R5F52617AxNE, R5F52617BxFL, R5F52617BxNE,<br>R5F52618AxFL, R5F52618AxNE, R5F52618BxFL, R5F52618BxNE  |
|                                    | 64pin  | R5F52616AxFM, R5F52616BxFM, R5F52617AxFM, R5F52617BxFM,<br>R5F52618AxFM, R5F52618BxFM   |
|                                    | 80pin  | R5F52616AxFN, R5F52616BxFN, R5F52617AxFN, R5F52617BxFN,<br>R5F52618AxFN, R5F52618BxFN   |
|                                    | 100pin | R5F52616AxFP, R5F52616BxFP, R5F52617AxFP, R5F52617BxFP,<br>R5F52618AxFP, R5F52618BxFP   |

## 2.2 Support Components List

Below is a list of Components supported by the Smart Configurator for RX V2.23.0.

Table 2-7 Support Components (RX100, RX200 family)

✓: Support, -: Non-support

| No | Components                                   | Mode                                   | RX110 | RX111 | RX113 | RX130 | RX13T | RX140 | RX230, RX231 | RX23E-A | RX23E-B | RX23T | RX23W | RX24T, RX24U | RX26T | RX260, RX261 | Remarks   |        |
|----|--|--|-------|-------|-------|-------|-------|-------|--------------|---------|---------|-------|-------|--------------|-------|--------------|-----------|--------|
| 1  | 8-Bit Timer                                  | -                                      | -     | -     | ✓     | ✓     | -     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
| 2  | CRC Calculator                               | -                                      | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
| 3  | D/A Converter                                | -                                      | -     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | -       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
| 4  | DMA Controller                               | -                                      | -     | -     | -     | -     | -     | ✓     | ✓            | ✓       | -       | ✓     | -     | ✓            | ✓     |              |           |        |
| 5  | I2C Slave Mode                               | I2C mode                               | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
|    |  | SMBus mode                             | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
| 6  | I2C Master Mode                              | I2C mode                               | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
|    |  | SMBus mode                             | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
| 7  | LCD Controller                               | -                                      | -     | ✓     | -     | -     | -     | -     | -            | ✓       | -       | -     | -     | -            | -     | -            |           |        |
| 8  | PWM Mode Timer                               | PWM mode 1                             | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            | -         |        |
|    |  | PWM mode 2                             | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            | -         |        |
| 9  | SCI/SCIF Clock Synchronous Mode              | Transmission                           | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            | Note 1, 2 |        |
|    |  | Reception                              | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            | Note 1, 2 |        |
|    |  | Transmission/Reception                 | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            | Note 1, 2 |        |
| 10 | SCI/SCIF Asynchronous Mode                   | Transmission                           | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            | Note 1    |        |
|    |  | Reception                              | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            | Note 1    |        |
|    |  | Transmission/Reception                 | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            | Note 1    |        |
|    |  | Multi-processor Transmission           | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            | ✓         | Note 1 |
|    |  | Multi-processor Reception              | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            | ✓         | Note 1 |
|    |  | Multi-processor Transmission/Reception | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            | ✓         | Note 1 |
| 11 | SPI Clock Synchronous Mode                   | Slave transmit/receive                 | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
|    |  | Slave transmit only                    | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
|    |  | Master transmit/receive                | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
|    |  | Master transmit only                   | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
| 12 | SPI Operation Mode                           | Slave transmit/receive                 | ✓     | ✓     | ✓     | ✓     | -     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
|    |  | Slave transmit only                    | ✓     | ✓     | ✓     | ✓     | -     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
|    |  | Master transmit/receive                | ✓     | ✓     | ✓     | ✓     | -     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
|    |  | Master transmit only                   | ✓     | ✓     | ✓     | ✓     | -     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
|    |  | Multi-master transmit/receive          | ✓     | ✓     | ✓     | ✓     | -     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
|    |  | Multi-master transmit only             | ✓     | ✓     | ✓     | ✓     | -     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |           |        |
| 13 | Event Link Controller                        | -                                      | -     | ✓     | ✓     | ✓     | -     | ✓     | ✓            | ✓       | -       | ✓     | -     | ✓            | ✓     |              |           |        |
| 14 | Watchdog Timer                               | -                                      | ✓     | ✓     | ✓     | ✓     | -     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     |              |           |        |
| 15 | Clock Frequency Accuracy Measurement Circuit | -                                      | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     |              |           |        |

Note 1. Refer to No 2 in Table 6-2

Note 2. Refer to No 3 in Table 6-2

Table 2-8 Support Components (RX100, RX200 family)

√: Support, -: Non-support

| No                       | Components                     | Mode  | RX110 | RX111 | RX113 | RX130 | RX13T | RX140 | RX230, RX231 | RX23E-A | RX23E-B | RX23T | RX23W | RX24T, RX24U | RX26T | RX260, RX261 | Remarks   |
|--------------------------|--------------------------------|---|-------|-------|-------|-------|-------|-------|--------------|---------|---------|-------|-------|--------------|-------|--------------|-----------|
| 16                       | Group Scan Mode S12AD          | -   | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            |           |
| 17                       | Comparator                     | -   | -     | -     | √     | √     | √     | √     | √            | -       | -       | -     | √     | -            | √     | √            |           |
| 18                       | Compare Match Timer            | -   | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            |           |
| 19                       | Single Scan Mode S12AD         | -   | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            |           |
| 20                       | Smart Card Interface Mode      | Transmission                                  | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            |           |
|                          |                                | Reception                                     | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            |           |
|                          |                                | Transmission/Reception                        | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            |           |
| 21                       | Dead-time Compensation Counter | -   | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | -     | √            | √     | -            |           |
| 22                       | Data Transfer Controller       | -   | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            | Note 3    |
| 23                       | Data Operation Circuit         | -   | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            |           |
| 24                       | Normal Mode Timer              | -   | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | -            |           |
| 25                       | Buses                          | -   | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            |           |
| 26                       | Programmable Pulse Generator   | -   | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | -            | -     | -            |           |
| 27                       | Ports                          | -   | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            |           |
| 28                       | Port Output Enable             | -   | -     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            |           |
| 29                       | Real Time Clock                | Binary  | √     | √     | √     | √     | -     | √     | √            | -       | √       | -     | √     | -            | -     | √            |           |
|                          |                                | Calendar                                      | √     | √     | √     | √     | -     | √     | √            | -       | √       | -     | √     | -            | -     | √            |           |
| 30                       | Remote Control Signal Receiver | -   | -     | -     | √     | -     | -     | -     | -            | -       | -       | -     | -     | -            | -     | √            |           |
| 31                       | Low-Power Timer                | -   | -     | -     | √     | √     | -     | √     | √            | √       | √       | -     | √     | -            | -     | √            |           |
| 32                       | Phase Counting Mode Timer      | 16-Bit Phase Counting Mode                    | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            | -         |
|                          |                                | Cascade Connection 32-Bit Phase Counting Mode | -     | -     | -     | -     | √     | -     | -            | -       | -       | √     | -     | √            | √     | -            |           |
| 33                       | Interrupt Controller           | -   | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            |           |
| 34                       | General PWM Timer              | Saw-wave PWM mode                             | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | -            | √     | √            | Note 4, 5 |
|                          |                                | Saw-wave one-shot pulse mode                  | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | -            | √     | √            | Note 4    |
|                          |                                | Triangle-wave PWM mode 1                      | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | -            | √     | √            | √         |
|                          |                                | Triangle-wave PWM mode 2                      | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | -            | √     | √            | √         |
|                          |                                | Triangle-wave PWM mode 3                      | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | -            | √     | √            | √         |
|                          |                                | Saw-wave PWM mode 2                           | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | -            | -     | √            | √         |
|                          |                                | Complementary PWM Mode 1                      | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | -            | -     | √            | √         |
|                          |                                | Complementary PWM Mode 2                      | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | -            | -     | √            | √         |
| Complementary PWM Mode 3 | -                              | -   | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | √            | √     |              |           |
| Complementary PWM Mode 4 | -                              | -   | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | √            | √     |              |           |
| 35                       | Low Power Consumption          | -   | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            |           |
| 36                       | Complementary PWM Mode Timer   | Complementary PWM mode 1                      | -     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            | -         |
|                          |                                | Complementary PWM mode 2                      | -     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            | -         |
|                          |                                | Complementary PWM mode 3                      | -     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √     | √            | -         |

Note 3. Refer to No 6 in Table 6-1

Note 4. Refer to No 1 in Table 6-1

Note 5. In RX26T, this mode is called as "Saw-wave PWM Mode 1"

**Table 2-9 Support Components (RX100, RX200 family)**

✓: Support, -: Non-support

| No | Components                      | Mode                                | RX110 | RX111 | RX113 | RX130 | RX13T | RX140 | RX230, RX231 | RX23E-A | RX23E-B | RX23T | RX23W | RX24T, RX24U | RX26T | RX260, RX261 | Remarks |
|----|---------------------------------|-------------------------------------|-------|-------|-------|-------|-------|-------|--------------|---------|---------|-------|-------|--------------|-------|--------------|---------|
| 37 | Continuous Scan Mode S12AD      | -                                   | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |         |
| 38 | Voltage Detection Circuit       | -                                   | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |         |
| 39 | Delta-Sigma Modulator Interface | Master                              | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | -            | -     | -            |         |
|    |                                 | Slave                               | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | -            | -     | -            | -       |
| 40 | Single Scan Mode DSAD           | -                                   | -     | -     | -     | -     | -     | ✓     | -            | ✓       | ✓       | -     | -     | -            | -     | -            |         |
| 41 | Continuous Scan Mode DSAD       | -                                   | -     | -     | -     | -     | -     | ✓     | -            | ✓       | ✓       | -     | -     | -            | -     | -            |         |
| 42 | Analog Front End                | -                                   | -     | -     | -     | -     | -     | ✓     | -            | ✓       | ✓       | -     | -     | -            | -     | -            |         |
| 43 | Motor                           | 3-Phase Brushless DC Motor          | -     | -     | -     | -     | ✓     | -     | -            | -       | -       | ✓     | -     | ✓            | ✓     | -            |         |
|    |                                 | 2-Phase Stepping Motor (Fast Decay) | -     | -     | -     | -     | ✓     | -     | -            | -       | -       | ✓     | -     | ✓            | ✓     | -            |         |
|    |                                 | 2-Phase Stepping Motor (Slow Decay) | -     | -     | -     | -     | ✓     | -     | -            | -       | -       | ✓     | -     | ✓            | ✓     | -            |         |

Table 2-10 Support Components (RX600, RX700 family)

✓: Support, -: Non-support

| No | Components                                   | Mode                                   | RX64M | RX65N, RX651 | RX66N | RX66T | RX660 | RX671 | RX71M | RX72M | RX72N | RX72T | Remarks   |
|----|--|--|-------|--------------|-------|-------|-------|-------|-------|-------|-------|-------|-----------|
| 1  | 8-Bit Timer                                  | -                                      | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
| 2  | CRC Calculator                               | -                                      | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
| 3  | D/A Converter                                | -                                      | ✓     | ✓            | ✓     | ✓     | ✓     | -     | ✓     | ✓     | ✓     | ✓     |           |
| 4  | DMA Controller                               | -                                      | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
| 5  | I2C Slave Mode                               | I2C mode                               | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
|    |  | SMBus mode                             | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
| 6  | I2C Master Mode                              | I2C mode                               | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
|    |  | SMBus mode                             | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
| 7  | LCD Controller                               | -                                      | -     | -            | -     | -     | -     | -     | -     | -     | -     | -     |           |
| 8  | PWM Mode Timer                               | PWM mode 1                             | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
|    |  | PWM mode 2                             | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
| 9  | SCI/SCIF Clock Synchronous Mode              | Transmission                           | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | Note 1, 2 |
|    |  | Reception                              | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | Note 1, 2 |
|    |  | Transmission/Reception                 | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | Note 1, 2 |
| 10 | SCI/SCIF Asynchronous Mode                   | Transmission                           | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | Note 1    |
|    |  | Reception                              | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | Note 1    |
|    |  | Transmission/Reception                 | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | Note 1    |
|    |  | Multi-processor Transmission           | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | Note 1    |
|    |  | Multi-processor Reception              | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | Note 1    |
|    |  | Multi-processor Transmission/Reception | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | Note 1    |
| 11 | SPI Clock Synchronous Mode                   | Slave transmit/receive                 | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
|    |  | Slave transmit only                    | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
|    |  | Master transmit/receive                | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
|    |  | Master transmit only                   | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
| 12 | SPI Operation Mode                           | Slave transmit/receive                 | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
|    |  | Slave transmit only                    | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
|    |  | Slave receive only                     | -     | -            | -     | -     | ✓     | ✓     | -     | -     | -     | -     |           |
|    |  | Master transmit/receive                | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
|    |  | Master transmit only                   | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
|    |  | Multi-master transmit/receive          | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
|    |  | Multi-master transmit only             | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
| 13 | Event Link Controller                        | -                                      | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
| 14 | Watchdog Timer                               | -                                      | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |
| 15 | Clock Frequency Accuracy Measurement Circuit | -                                      | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |           |

Note 1. Refer to No 2 in Table 6-2

Note 2. Refer to No 3 in Table 6-2

Table 2-11 Support Components (RX600, RX700 family)

√: Support, -: Non-support

| No | Components                     | Mode  | RX64M | RX65N, RX651 | RX66N | RX66T | RX660 | RX671 | RX71M | RX72M | RX72N | RX72T  | Remarks |
|----|--------------------------------|---|-------|--------------|-------|-------|-------|-------|-------|-------|-------|--------|---------|
| 16 | Group Scan Mode S12AD          | -   | √     | √            | √     | √     | √     | √     | √     | √     | √     | √      |         |
| 17 | Comparator                     | -   | -     | -            | √     | √     | -     | -     | √     | -     | √     |        |         |
| 18 | Compare Match Timer            | -   | √     | √            | √     | √     | √     | √     | √     | √     | √     | √      |         |
| 19 | Single Scan Mode S12AD         | -   | √     | √            | √     | √     | √     | √     | √     | √     | √     | √      |         |
| 20 | Smart Card Interface Mode      | Transmission                                  | √     | √            | √     | √     | √     | √     | √     | √     | √     | √      |         |
|    |                                | Reception                                     | √     | √            | √     | √     | √     | √     | √     | √     | √     | √      |         |
|    |                                | Transmission/Reception                        | √     | √            | √     | √     | √     | √     | √     | √     | √     | √      |         |
| 21 | Dead-time Compensation Counter | -   | √     | √            | √     | √     | √     | √     | √     | √     | √     |        |         |
| 22 | Data Transfer Controller       | -   | √     | √            | √     | √     | √     | √     | √     | √     | √     | Note 3 |         |
| 23 | Data Operation Circuit         | -   | √     | √            | √     | √     | √     | √     | √     | √     | √     |        |         |
| 24 | Normal Mode Timer              | -   | √     | √            | √     | √     | √     | √     | √     | √     | √     |        |         |
| 25 | Buses                          | -   | √     | √            | √     | √     | √     | √     | √     | √     | √     |        |         |
| 26 | Programmable Pulse Generator   | -   | √     | √            | √     | -     | -     | √     | √     | -     | √     | -      |         |
| 27 | Ports                          | -   | √     | √            | √     | √     | √     | √     | √     | √     | √     | √      |         |
| 28 | Port Output Enable             | -   | √     | √            | √     | √     | √     | √     | √     | √     | √     | √      |         |
| 29 | Real Time Clock                | Binary  | √     | √            | √     | -     | √     | √     | √     | -     | √     | -      |         |
|    |                                | Calendar                                      | √     | √            | √     | -     | √     | √     | √     | -     | √     | -      |         |
| 30 | Remote Control Signal Receiver | -   | -     | -            | -     | √     | √     | -     | -     | -     | -     |        |         |
| 31 | Low-Power Timer                | -   | -     | -            | -     | -     | -     | -     | -     | -     | -     |        |         |
| 32 | Phase Counting Mode Timer      | 16-Bit Phase Counting Mode                    | √     | √            | √     | √     | √     | √     | √     | √     | √     | √      |         |
|    |                                | Cascade Connection 32-Bit Phase Counting Mode | √     | √            | √     | √     | √     | √     | √     | √     | √     | √      |         |
| 33 | Interrupt Controller           | -   | √     | √            | √     | √     | √     | √     | √     | √     | √     | √      |         |
| 34 | General PWM Timer              | Saw-wave PWM mode                             | √     | -            | √     | √     | -     | -     | √     | √     | √     | √      | Note 4  |
|    |                                | Saw-wave one-shot pulse mode                  | √     | -            | √     | √     | -     | -     | √     | √     | √     | √      | Note 4  |
|    |                                | Triangle-wave PWM mode 1                      | √     | -            | √     | √     | -     | -     | √     | √     | √     | √      | Note 4  |
|    |                                | Triangle-wave PWM mode 2                      | √     | -            | √     | √     | -     | -     | √     | √     | √     | √      | Note 4  |
|    |                                | Triangle-wave PWM mode 3                      | √     | -            | √     | √     | -     | -     | √     | √     | √     | √      | Note 4  |
| 35 | Low Power Consumption          | -   | √     | √            | √     | √     | √     | √     | √     | √     | √     |        |         |
| 36 | Complementary PWM Mode Timer   | Complementary PWM mode 1                      | √     | √            | √     | √     | √     | √     | √     | √     | √     | √      |         |
|    |                                | Complementary PWM mode 2                      | √     | √            | √     | √     | √     | √     | √     | √     | √     | √      |         |
|    |                                | Complementary PWM mode 3                      | √     | √            | √     | √     | √     | √     | √     | √     | √     | √      |         |
| 37 | Continuous Scan Mode S12AD     | -   | √     | √            | √     | √     | √     | √     | √     | √     | √     |        |         |

Note 3. Refer to No 6 in Table 6-1

Note 4. Refer to No 1 in Table 6-1

Table 2-12 Support Components (RX600, RX700 family)

✓: Support, -: Non-support

| No | Components                      | Mode                                | RX64M | RX65N, RX651 | RX66N | RX66T | RX660 | RX671 | RX71M | RX72M | RX72N | RX72T | Remarks |
|----|---------------------------------|-------------------------------------|-------|--------------|-------|-------|-------|-------|-------|-------|-------|-------|---------|
| 38 | Voltage Detection Circuit       | -                                   | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |         |
| 39 | Delta-Sigma Modulator Interface | Master                              | -     | -            | -     | -     | -     | -     | -     | ✓     | -     | -     |         |
|    |                                 | Slave                               | -     | -            | -     | -     | -     | -     | -     | ✓     | -     | -     |         |
| 40 | Single Scan Mode DSAD           | -                                   | -     | -            | -     | -     | -     | -     | -     | -     | -     | -     |         |
| 41 | Continuous Scan Mode DSAD       | -                                   | -     | -            | -     | -     | -     | -     | -     | -     | -     | -     |         |
| 42 | Analog Front End                | -                                   | -     | -            | -     | -     | -     | -     | -     | -     | -     | -     |         |
| 43 | Motor                           | 3-Phase Brushless DC Motor          | -     | -            | -     | ✓     | -     | -     | -     | ✓     | -     | ✓     |         |
|    |                                 | 2-Phase Stepping Motor (Fast Decay) | -     | -            | -     | ✓     | -     | -     | -     | ✓     | -     | ✓     |         |
|    |                                 | 2-Phase Stepping Motor (Slow Decay) | -     | -            | -     | ✓     | -     | -     | -     | ✓     | -     | ✓     |         |

## 2.3 New support

### 2.3.1 Update BSP (Board Support Package) revision

From Smart Configurator for RX V2.23.0, BSP rev7.51 is supported and added as default BSP when creating new SC project.

### 2.3.2 Update RX260, RX261 revision

From Smart Configurator for RX V2.23.0, it is updated to synchronize with the latest User's Manual Hardware rev1.00.

### 2.3.3 Support GCC RX Toolchain for Smart Configurator standalone

From Smart Configurator for RX V2.23.0, GCC RX Toolchain can be selected when creating new configuration file.




Figure 2-1 New Smart Configuration File dialog



### 2.3.4 Support CMake generation for Smart Configurator with Visual Studio Code

When using Visual Studio Code with Renesas Debug extension v24.9.0 or later to create RX project with Smart Configurator V2.23.0, CMake project is generated for easier build on VS Code.

Both CC-RX toolchain and GCC RX toolchain are supported for CMake generation.




Figure 2-2 CMake project is generated for VS Code

### 2.3.5 Add WAIT\_LOOP comment

From Smart Configurator for RX V2.23.0, WAIT\_LOOP comment is added to the generated code. Users can search with this key word to identify the potential code with infinite loop.

```

Config_RTC.c ×
/* RTC cold start with sub-clock source or RTC start with main clock source */
if((0 == SYSTEM.RSTS1.BIT.CWSF) || (_01_RTC_SOURCE_SELECT_MAIN_FORCED == RTC.RCR4.BYTE))
{
    /* Stop all counters */
    RTC.RCR2.BYTE = 0x00U;
    /* WAIT_LOOP */
    while (RTC.RCR2.BIT.START != 0U)
    {
        /* Wait for the register modification to complete */
    }
    /* Select count mode */
    RTC.RCR2.BIT.CNTMD = 1U;
    /* WAIT_LOOP */
    while (RTC.RCR2.BIT.CNTMD != 1U)
    {
        /* Wait for the register modification to complete */
    }
}
    
```

Figure 2-3 WAIT\_LOOP comment is added

### 2.3.6 Support encoder and hall sensor for Motor component

From Smart Configurator for RX V2.23.0, Motor component supports setting for encoder and hall sensor.




Figure 2-4 Encoder and hall sensor setting of Motor configuration

### 2.3.7 Support magnet sensor for Motor component

From Smart Configurator for RX V2.23.0, Motor component supports setting for magnet sensor (digital output).

Applicable devices: RX24T




Figure 2-5 Magnet sensor setting of Motor configuration

### 3. Changes

This chapter describes changes to the Smart Configurator for RX V2.23.0.

#### 3.1 Correction of issues/limitations

##### 3.1.1 Fixed I2C master mode with ACK/NACK interrupts

When using I2C master mode with ACK/NACK interrupts setting and calling API `R_Config_SCIx_IIC_Master_Send` with invalid slaver address or slaver device disconnected, `SCIx.RDR` value is written to memory area started from `0x00000000` address.

Applicable devices: all RX devices

This issue has been fixed from SC for RX V2.23.0.

##### 3.1.2 Fixed Group Scan Mode S12AD with group priority control

When using Group Scan Mode S12AD component with group priority control setting, the results of scanning operation may be incorrect.

Applicable devices: RX devices except RX110, RX111, RX113 (not support group priority control setting)

This issue has been fixed from SC for RX V2.23.0.

##### 3.1.3 Fixed Continuous Scan Mode S12AD with channel 0

When using Continuous Scan Mode S12AD component with channel 0 and self-diagnostic setting enabled, error occurs in reopening the Smart Configurator project.

Applicable devices: RX651, RX65N

This issue has been fixed from SC for RX V2.23.0.

##### 3.1.4 Fixed Buses with 8-bit data width

When using Buses component with 8-bit data width, the unrelated D8-D15 pins are also assigned.

Applicable devices: RX64M 100-pin, RX651 100-pin, RX65N 100-pin, RX71M 100-pin

This issue has been fixed from SC for RX V2.23.0

##### 3.1.5 Fixed Developer Assistance for I2C Master Mode

When using I2C Master Mode component on e<sup>2</sup> studio, the Developer Assistance does not display its API.

Applicable devices: RX23E-B, RX26T, RX260, RX261, RX660

This issue has been fixed from SC for RX V2.23.0

### 3.2 Specification changes

#### 3.2.1 Improve Clock warning icon

From Smart Configurator for RX V2.23.0, warning icon is displayed for both CANFDCLK clock and CANFDMCLK/CAMCLK clock.

Applicable devices: RX26T, RX261, RX660




Figure 3-1 Warning icon at Clock

### 3.2.2 Improve Real Time Clock generated code

From Smart Configurator for RX V2.23.0, the generated code for R\_Config\_RTC\_Create function is improved to remove unnecessary code.

```
void R_Config_RTC_Create(void)
{
    uint16_t w_count;
    uint32_t rw_count;
    volatile uint32_t dummy;

    /* Disable ALM, PRD and CUP interrupts */
    IEN(RTC, ALM) = 0U;
    IEN(RTC, PRD) = 0U;

    if (RTC.RCR1.BIT.AIE == 1U)
    {
        /* Disable RTC ALARM interrupt */
        RTC.RCR1.BIT.AIE = 0U;
        /* WAIT_LOOP */
        while (RTC.RCR1.BIT.AIE != 0U)
        {
            /* Wait for the register modification to complete */
        }

        /* Clear IR flag of ICU ALARM interrupt */
        IR(RTC, ALM) = 0U;
    }
}
```

Figure 3-2 Unnecessary code of R\_Config\_RTC\_Create function

### 3.2.3 Improve application selection UI of RTOS

From Smart Configurator for RX V2.23.0, there is new checkbox to show only supported application by default during project generation.




Figure 3-3 Application selection page for FreeRTOS

### 3.2.4 Improve API name of Motor component

From Smart Configurator for RX V2.23.0, there is small change at API name of Motor component.

Old API:

R\_Config\_MOTOR\_EncoderSpeedCal**C**TimerStart

New API:

R\_Config\_MOTOR\_EncoderSpeedCal**c**TimerStart

There is no impact to application code using old API name as there is a macro to convert old API name to new API name.

#### 4. List of RENESAS TOOL NEWS AND TECHNICAL UPDATE

Below is a list of notifications delivered by RENESAS TOOL NEWS and TECHNICAL UPDATE.

| Issue date    | Document No. | Description   | Applicable MCUs   | Fixed version |
|---------------|--------------|---|---|---------------|
| Sep. 1, 2017  | R20TS0198    | 1. When using the I2C bus interface in slave mode<br><a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx</a>  | RX130,<br>RX64M,<br>RX651,<br>RX65N   | V1.3.0        |
| Apr. 1, 2018  | R20TS0294    | 1. When using the bus for peripheral functions<br><a href="https://www.renesas.com/document/tnn/notes-cs-smart-configurator-rx-e-studio-smart-configurator-plug">https://www.renesas.com/document/tnn/notes-cs-smart-configurator-rx-e-studio-smart-configurator-plug</a>   | RX230,<br>RX231   | V1.4.0        |
| Oct. 01, 2018 | R20TS0351    | 1. Setting TPU0 channel of PWM Mode Timer<br><a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-0">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-0</a>  | RX65N,<br>RX651,<br>RX64M   | V1.5.0        |
| Feb.01, 2019  | R20TS0401    | 1. Point for caution when using the GTIOcnm pin (n = 0 to 9, m = A, B) of the general PWM timer (GPTW) as a hardware source<br><a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-1">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-1</a>  | RX66T   | V2.1.0        |
| Apr.16, 2019  | R20TS0425    | 1. When using the I2C bus interface in master mode<br><a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-2">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-2</a>   | RX110,<br>RX111,<br>RX113,<br>RX130,<br>RX230,<br>RX231,<br>RX23T,<br>RX24T,<br>RX24U,<br>RX64M,<br>RX651,<br>RX65N,<br>RX71M | V2.2.0        |
| Jun.01, 2019  | R20TS0434    | 1. When using self-diagnosis function of 12-bit A/D converter in Single Scan Mode<br>2. When using Serial Peripheral Interface clock synchronous mode in slave transmit<br>3. When using I2C Bus Interface with Fast-mode Plus enabled<br><a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-3">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-3</a> | RX230,<br>RX231,<br>RX66T,<br>RX72T,<br>RX64M,<br>RX651,<br>RX65N,<br>RX71M   | V2.2.0        |



| Issue date    | Document No. | Description   | Applicable MCUs   | Fixed version |
|---------------|--------------|---|---|---------------|
| Jun.16, 2019  | R20TS0436    | 1. When using general PWM timer<br><a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-4">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-4</a>  | RX66T,<br>RX72T   | V2.2.0        |
| Aug.01, 2019  | R20TS0466    | 1. When using the NACK reception transfer suspension function on the I <sup>2</sup> C bus interface<br><a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-5">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-5</a>  | RX110,<br>RX111,<br>RX113,<br>RX130,<br>RX230,<br>RX231,<br>RX23T,<br>RX24T,<br>RX24U,<br>RX64M,<br>RX651,<br>RX65N,<br>RX66T,<br>RX71M,<br>RX72M,<br>RX72T | V2.3.0        |
| Sep.16, 2019  | R20TS0477    | 1. When Using the Automatic Adjustment Function for Time Error Adjustment on the Realtime Clock<br><a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-6">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-6</a>  | RX110,<br>RX111,<br>RX113,<br>RX130,<br>RX230,<br>RX231,<br>RX64M,<br>RX651,<br>RX65N   | V2.4.0        |
| Dec.16, 2019  | R20TS0522    | 1. When using temperature sensor output or internal reference voltage for comparison function on S12AD components (Single Scan Mode, Group Scan Mode and Continuous Scan Mode)<br>2. When using calendar mode API to set counter value on RTC component<br>3. When using window B for comparison function on S12AD Continuous Scan Mode component<br>4. When using double trigger mode on S12AD Single Scan Mode component<br><a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-7">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-7</a> | RX64M,<br>RX651,<br>RX65N,<br>RX66T,<br>RX71M,<br>RX72M,<br>RX72T   | V2.4.0        |
| Feb. 01, 2020 | R20TS0546    | 1. When using the PLL frequency synthesizer of the clock<br><a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-8">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-8</a>   | RX64M,<br>RX651,<br>RX65N,<br>RX66T,<br>RX71M,<br>RX72T   | V2.5.0        |

| Issue date    | Document No.    | Description   | Applicable MCUs                          | Fixed version |
|---------------|-----------------|---|--|---------------|
| Mar. 16, 2020 | R20TS0555       | <ol style="list-style-type: none"> <li>When using the TGIC7 and TGID7 interrupts in Normal Mode Timer or PWM Mode Timer</li> <li>When creating a project with RX24T 64-pin FK packages</li> <li>When using compare level of AN109 in Single Scan Mode S12AD</li> </ol> <a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-9">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-9</a>  | RX24T, RX24U, RX71M                      | V2.5.0        |
| Apr.03, 2020  | TN-RX*-A0222    | Errata to RX72N Group User's Manual: Hardware Rev.1.00<br><a href="https://www.renesas.com/document/tcu/errata-rx72n-group-users-manual-hardware-rev100">https://www.renesas.com/document/tcu/errata-rx72n-group-users-manual-hardware-rev100</a>   | RX72N                                    | V2.5.0        |
| May.16, 2020  | R20TS0579       | <ol style="list-style-type: none"> <li>When using Stop API in Continuous Scan Mode DSAD and Single Scan Mode DSAD components</li> </ol> <a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-10">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-10</a>   | RX23E-A                                  | V2.6.0        |
| Jun.16, 2020  | R20TS0591       | <ol style="list-style-type: none"> <li>When using Data Transfer Controller (DTC) component and making configuration for its vector base address</li> <li>When using SCI/SCIF Asynchronous Mode component and making configuration for its bit-rate</li> <li>When using AN007 or AN107 as analog input pins in S12AD components</li> </ol> <a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-11">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-11</a> | RX230, RX231, RX651, RX65N, RX66T, RX72T | V2.6.0        |
| Aug. 21, 2020 | TN-RX*-A0234A/E | Errata to the RX113 Group User's Manual: Hardware Rev.1.10<br><a href="https://www.renesas.com/document/tcu/errata-rx113-group-users-manual-hardware">https://www.renesas.com/document/tcu/errata-rx113-group-users-manual-hardware</a>   | RX113                                    | V2.8.0        |
| Sep. 01, 2020 | R20TS0611       | When using PWM Mode component and making configuration with MTU channel 1 and 2<br><a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-13">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-13</a>  | RX13T, RX23T, RX24T, RX24U               | V2.7.0        |

| Issue date    | Document No.    | Description   | Applicable MCUs   | Fixed version |
|---------------|-----------------|---|---|---------------|
| Sep. 24, 2020 | TN-RX*-A0235B/E | Notes on the Transmit Data Empty Interrupt When the FIFO is in Use with the Serial Communications Interface (SCI)<br><a href="https://www.renesas.com/document/tcu/notes-transmit-data-empty-interrupt-when-fifo-use-serial-communications-interface-sci">https://www.renesas.com/document/tcu/notes-transmit-data-empty-interrupt-when-fifo-use-serial-communications-interface-sci</a>  | RX651,<br>RX65N,<br>RX66N,<br>RX66T,<br>RX72M,<br>RX72N,<br>RX72T                     | V2.7.0        |
| Oct. 01, 2020 | R20TS0623       | 1. When using “r_sci_rx” component and making pin configurations for RXD and TXD<br>2. When using “r_sci_rx” component, duplicate SCI11 channels are displayed in the Components configuration panel<br><a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-12">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-12</a> | RX651,<br>RX65N,<br>RX66N,<br>RX72M,<br>RX72N   | V2.7.0        |
| Dec. 01, 2020 | R20TS0638       | 1. Note on setting timer operation period in Motor component.<br>2. When loading project with port configuration created in V2.5.0 or version before into V2.6.0 version onwards<br><a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-14">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-14</a>                     | RX13T,<br>RX23T,<br>RX24T,<br>RX24U,<br>RX651,<br>RX65N,<br>RX66T,<br>RX72T,<br>RX72M | V2.8.0        |
| Aug. 29, 2017 | TN-RX*-A180A/E  | Restriction for the PH7/XCIN Pin<br><a href="https://www.renesas.com/document/tcu/restriction-ph7xcin-pin">https://www.renesas.com/document/tcu/restriction-ph7xcin-pin</a>   | RX110,<br>RX111,<br>RX113   | V2.9.1        |
| May. 16, 2021 | R20TS0696       | When using PORT component and configuring PORTC multiplexed pins as input<br><a href="https://www.renesas.com/us/en/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-15">https://www.renesas.com/us/en/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-15</a>  | RX130,<br>RX230,<br>RX231   | V2.10.0       |
| Aug. 01, 2021 | R20TS0735       | When using Port Output Enable (POE) component and configuring MTU pins as high impedance<br><a href="https://www.renesas.com/sg/zh/document/tnn/notes-e2-studio-smart-configurator-plug-smart-configurator-rx">https://www.renesas.com/sg/zh/document/tnn/notes-e2-studio-smart-configurator-plug-smart-configurator-rx</a>   | RX23W,<br>RX24T,<br>RX64M,<br>RX651,<br>RX71M,<br>RX72M                               | V2.11.0       |

| Issue date    | Document No.    | Description  | Applicable MCUs   | Fixed version |
|---------------|-----------------|--|---|---------------|
| Nov. 16, 2021 | R20TS0770       | When using Port component and configuring port pins' driving ability as high drive output<br><a href="https://www.renesas.com/us/en/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-16">https://www.renesas.com/us/en/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-16</a>   | RX651,<br>RX65N   | V2.12.0       |
| Mar. 01, 2022 | R20TS0820       | 1. When importing existing C++ project and updating BSP component version to 7.00 onwards<br><br>2. When build or clean e <sup>2</sup> studio Smart Configurator project<br><br>3. When using AN107 in S12AD Continuous Scan Mode component<br><a href="https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-17">https://www.renesas.com/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-17</a> | RX110,<br>RX111,<br>RX113,<br>RX130,<br>RX13T,<br>RX140,<br>RX230,<br>RX231,<br>RX23E-A,<br>RX23T,<br>RX23W,<br>RX24T,<br>RX24U,<br>RX651,<br>RX65N,<br>RX66N,<br>RX66T,<br>RX671,<br>RX72M,<br>RX72N,<br>RX72T,<br>RX64M,<br>RX71M | V2.13.0       |
| Feb. 01, 2023 | R20TS0920       | When using DA component to provide reference input voltage for Comparator component<br><a href="https://www.renesas.com/us/en/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-18">https://www.renesas.com/us/en/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-18</a>   | RX13T,<br>RX23T,<br>RX24T,<br>RX24U,<br>RX66T,<br>RX72T   | V2.17.0       |
| Mar. 16, 2023 | R20TS0931       | When using S12AD Continuous Scan Mode component and making configuration for channel AN117 to AN119<br><a href="https://www.renesas.com/us/en/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-19">https://www.renesas.com/us/en/document/tnn/notes-e-studio-smart-configurator-plug-smart-configurator-rx-19</a>   | RX651/N   | V2.17.0       |
| Feb 9, 2024   | TN-RX*-A0275A/E | Notes on the Selection of the Clock Sources for RSCI8 and RSCI9 in the RX26T Group<br><a href="https://www.renesas.com/us/en/document/tcu/notes-selection-clock-sources-rsci8-and-rsci9-rx26t-group?r=25424951">https://www.renesas.com/us/en/document/tcu/notes-selection-clock-sources-rsci8-and-rsci9-rx26t-group?r=25424951</a>  | RX26T   | V2.21.0       |

| Issue date   | Document No. | Description  | Applicable MCUs | Fixed version |
|--------------|--------------|--|-----------------|---------------|
| Sep 20, 2024 | R20TS1067    | Notes on using Continuous Scan Mode S12AD component<br><a href="https://www.renesas.com/en/document/tn/notes-e-studio-studio-smart-configurator-plug-smart-configurator-rx?r=1504491">https://www.renesas.com/en/document/tn/notes-e-studio-studio-smart-configurator-plug-smart-configurator-rx?r=1504491</a> | RX651,<br>RX65N | V2.23.0       |

## 5. Points for Limitation

This section describes points for limitation regarding the Smart Configurator for RX V2.23.0. Regarding FIT component driver limitation, please refer to its document generated out after code generation.

### 5.1 List of Limitation

Table 5-1 List of limitations (RX100, RX200 family)

✓: Applicable, -: Not Applicable

| No | Description  | RX110 | RX111 | RX113 | RX130 | RX13T | RX140 | RX230, RX231 | RX23E-A | RX23E-B | RX23T | RX23W | RX24T, RX24U | RX26T | RX260, RX261 | Remarks |
|----|--|-------|-------|-------|-------|-------|-------|--------------|---------|---------|-------|-------|--------------|-------|--------------|---------|
| 1  | Note on general I/O port direction issue on MCU package view when using Port Component | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |         |
| 2  | Note on the resource tree in the FIT component GUI configuration                       | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |         |
| 3  | Note on address pin when using external bus  | -     | -     | -     | -     | -     | ✓     | -            | -       | -       | ✓     | -     | -            | -     | -            |         |
| 4  | Note on Port module combo box in ELC component when using Port component               | -     | -     | -     | -     | -     | ✓     | -            | ✓       | ✓       | -     | ✓     | -            | ✓     | ✓            |         |
| 5  | Note on tab display on Mac OS  | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |         |
| 6  | Note on bus priority setting   | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓            | ✓       | ✓       | ✓     | ✓     | ✓            | ✓     | ✓            |         |
| 7  | Note on RTC with main clock  | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | -            | -     | -            |         |

Table 5-2 List of Limitation (RX600, RX700 family)

✓: Applicable, -: Not Applicable

| No | Description  | RX64M | RX65N, RX651 | RX66N | RX66T | RX660 | RX671 | RX71M | RX72M | RX72N | RX72T | Remarks |
|----|--|-------|--------------|-------|-------|-------|-------|-------|-------|-------|-------|---------|
| 1  | Note on the general I/O port direction issue on MCU package view when using Port Component | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |         |
| 2  | Note on the resource tree in the FIT component GUI configuration                           | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |         |
| 3  | Note on address pin when using external bus  | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |         |
| 4  | Note on Port module combo box in ELC component when using Port component                   | -     | -            | ✓     | -     | ✓     | ✓     | -     | ✓     | ✓     | -     |         |
| 5  | Note on tab display on Mac OS  | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |         |
| 6  | Note on bus priority setting   | ✓     | ✓            | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     | ✓     |         |
| 7  | Note on RTC with main clock  | ✓     | ✓            | ✓     | -     | -     | ✓     | ✓     | ✓     | ✓     | -     |         |

## 5.2 Details of Limitation

### 5.2.1 Note on the general I/O port direction issue on MCU package view when using Port Component

When adding two configurations for Port component and set different direction for the same port pin in these two configurations, e.g., set P14 as output in 1st configuration while P14 as input in the 2nd configuration, after that remove the 2nd configuration, but now the P14 direction is marked as 'I' on the MCU package view for 1st configuration.

### 5.2.2 Note on the resource tree in the FIT component GUI configuration


When configuring the FIT component, the resource tree is still visible even there is no pins under it, for such case it will be hidden from next release.

| Property                                 | Value |
|--|-------|
| # RX FIFO threshold for channel 9        | 8     |
| # RX FIFO threshold for channel 10       | 8     |
| # RX FIFO threshold for channel 11       | 8     |
| # Received data match function for chann | Not   |
| # Received data match function for chann | Not   |
| # Received data match function for chann | Not   |
| # Received data match function for chann | Not   |
| # Received data match function for chann | Not   |
| # Received data match function for chann | Not   |
| # Received data match function for chann | Not   |
| # Received data match function for chann | Not   |
| # Received data match function for chann | Not   |
| # Received data match function for chann | Not   |
| # Received data match function for chann | Not   |
| # Received data match function for chann | Not   |
| # Received data match function for chann | Not   |
| Resources                                |       |
| SCI                                      |       |

Figure 5-1 Resource tree without any pin in FIT component GUI

**5.2.3 Note on address bus when using external bus**


When using Address/Data multiplexed bus in external bus, disable all unnecessary address output pin settings.



**Figure 5-2 “Address output pin setting” value should be disabled**

**5.2.4 Note on Port module combo box in ELC component when using Port component**

When using ELC component, the status of items in the Port module combo box is not updated correctly when changing the status (e.g., check > uncheck > check) of ports in Port selection tab of Port component.



**Figure 5-3 The relationship between the Port component and the ELC component**



To solve this issue, after you have changed the status (e.g., check > uncheck > check) of ports in Port selection tab, please re-configure the settings of ports that you want to link with ELC components.




Figure 5-4 The settings the port needs to be re-configured

### 5.2.5 Note on tab display on Mac OS

When using some Code Generator components with dynamic tab like PORT on Mac OS environment, the text of last tab may not be displayed fully, however, it can be selected and works as normal.




Figure 5-5 Tab display of PORT on Mac OS

### 5.2.6 Note on bus priority setting

When using BSP from rev7.42 and newer, there are some settings for bus priority as following.




Figure 5-6 BSP bus priority setting

If you also use Buses component, please take note that it does not synchronize the settings between Buses and BSP, and the settings at Buses component is applied.




Figure 5-7 Bus priority setting with Buses component

### 5.2.7 Note on RTC with main clock

When using RTC component with main clock setting as counting source, you may observe an infinite loop in the R\_Config\_RTC\_Create function after software reset.

To avoid this issue, please modify the following code of clock\_source\_select function of mcu\_clocks.c file.

```

/* Cold start setting */
if (0 == SYSTEM.RSTSR1.BIT.CWSF)
{
    /* Stop the sub-clock oscillator */
    /* RCR4 - RTC Control Register 4
    b7:b1   Reserved - The write value should be 0.
    b0      RCKSEL   - Count Source Select - Sub-clock oscillator is selected. */
    RTC.RCR4.BIT.RCKSEL = 1;

    /* WAIT_LOOP */
    for (i = 0; i < 4; i++)
    {
        /* dummy read four times */
        dummy = RTC.RCR4.BYTE;
    }
}

```

Figure 5-8 Workaround code at clock\_source\_select function

## 6. Points for Caution

This section describes points for caution regarding the Smart Configurator for RX V2.23.0. Regarding FIT component driver caution, please refer to its document generated out after code generation.

### 6.1 List of Caution

Table 6-1 List of Caution (RX100, RX200 family)

√: Applicable, -: Not Applicable

| No | Description  | RX110 | RX111 | RX113 | RX130 | RX13T | RX140 | RX230, RX231 | RX23E-A | RX23E-B | RX23T | RX23W | RX24T, RX24U | RX260, RX261 | Remarks |
|----|--|-------|-------|-------|-------|-------|-------|--------------|---------|---------|-------|-------|--------------|--------------|---------|
| 1  | Note on configuring GPT interrupt  | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | √            | √            | √       |
| 2  | Note on using only reception in SCI Clock Synchronous Mode                             | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √            |         |
| 3  | Notes on using high transfer speed in SCIF Synchronous Mode                            | -     | -     | -     | -     | -     | -     | -            | -       | -       | -     | -     | -            | -            |         |
| 4  | Note on device change functionality  | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √            |         |
| 5  | Note on using Smart Configurator for GCC project in e <sup>2</sup> studio 7.4.0        | √     | √     | √     | √     | √     | -     | √            | √       | √       | √     | -     | √            | √            |         |
| 6  | Note on using Data Transfer Controller   | -     | -     | -     | -     | √     | √     | -            | √       | √       | -     | -     | -            | √            | √       |
| 7  | Note on Ports setting when using S12AD components                                      | √     | -     | √     | √     | -     | √     | -            | -       | -       | -     | √     | -            | -            | √       |
| 8  | Note on section build warning when using FIT components                                | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √            |         |
| 9  | Note on C++ project support in CS+   | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √            |         |
| 10 | Note on Installation directory   | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √            |         |
| 11 | Note on the build error of RTOS C++ project  | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √            |         |
| 12 | Note on the output of high impedance issue for TXDn pin                                | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √            |         |
| 13 | Note on the include path update issue when renaming the component's configuration name | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √            |         |
| 14 | Note on accessing "Release Notes" and "Tool News" URL from the help menu               | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √            |         |
| 15 | Note on the IPCF file naming change for IAR project                                    | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √            |         |
| 16 | Note on using user code protection feature   | √     | √     | √     | √     | √     | √     | √            | √       | √       | √     | √     | √            | √            |         |
| 17 | Note on code generation difference at Component tab and not at Component tab           | √     | √     | √     | √     | -     | √     | √            | -       | √       | -     | -     | -            | -            |         |

Table 6-2 List of Caution (RX600, RX700 family)

√: Applicable, -: Not Applicable

| No | Description  | RX64M | RX65N, RX651 | RX66N | RX66T | RX660 | RX671 | RX71M | RX72M | RX72N | RX72T | Remarks |
|----|--|-------|--------------|-------|-------|-------|-------|-------|-------|-------|-------|---------|
| 1  | Note on configuring GPT interrupt  | √     | -            | √     | √     | -     | -     | √     | √     | √     | √     |         |
| 2  | Note on using only reception in SCI Clock Synchronous Mode                             | √     | √            | √     | √     | √     | √     | √     | √     | √     | √     |         |
| 3  | Notes on using high transfer speed in SCIF Synchronous Mode                            | √     | -            | -     | -     | -     | -     | √     | -     | -     | -     |         |
| 4  | Note on device change functionality  | √     | √            | √     | √     | √     | √     | √     | √     | √     | √     |         |
| 5  | Note on using Smart Configurator for GCC project in e <sup>2</sup> studio 7.4.0        | √     | √            | √     | √     | -     | -     | √     | -     | √     | √     |         |
| 6  | Note on using Data Transfer Controller   | -     | √            | √     | -     | √     | √     | -     | √     | √     | -     |         |
| 7  | Note on Ports setting when using S12AD components                                      | √     | √            | √     | -     | -     | √     | √     | √     | √     | -     |         |
| 8  | Note on section build warning when using FIT components                                | √     | √            | √     | √     | √     | √     | √     | √     | √     | √     |         |
| 9  | Note on C++ project support in CS+   | √     | √            | √     | √     | √     | √     | √     | √     | √     | √     |         |
| 10 | Note on Installation directory   | √     | √            | √     | √     | √     | √     | √     | √     | √     | √     |         |
| 11 | Note on the build error of existing RTOS C++ project                                   | √     | √            | √     | √     | -     | √     | √     | √     | √     | √     |         |
| 12 | Note on the output of high impedance issue for TXDn pin                                | √     | √            | √     | √     | √     | √     | √     | √     | √     | √     |         |
| 13 | Note on the include path update issue when renaming the component's configuration name | √     | √            | √     | √     | √     | √     | √     | √     | √     | √     |         |
| 14 | Note on accessing "Release Notes" and "Tool News" URL from the help menu               | √     | √            | √     | √     | √     | √     | √     | √     | √     | √     |         |
| 15 | Note on the IPCF file naming change for IAR project                                    | √     | √            | √     | √     | √     | √     | √     | √     | √     | √     |         |
| 16 | Note on using user code protection feature   | √     | √            | √     | √     | √     | √     | √     | √     | √     | √     |         |
| 17 | Note on code generation difference at Component tab and not at Component tab           | √     | √            | -     | -     | -     | -     | √     | -     | -     | -     |         |

## 6.2 Details of Caution

### 6.2.1 Note on configuring GPT interrupts

The GPT interrupts are not specified as the Software Configurable Interrupt in the initial state even after the GPT interrupts are configured by GPT component. To specify GPT interrupts as Software Configurable Interrupt source, release unused Software Configurable interrupt source on the Interrupt sheet and allocate GPT interrupts instead.




Figure 6-1 GPT interrupt vector number assignment

### 6.2.2 Note on using only reception in SCI Clock Synchronous Mode

In SCI Clock Synchronous Mode using internal clock, if only reception is enabled in high communication speed, extra clocks are generated even though reception has been completed.

This is due to the delay in disabling RE to stop the clock after the desired number of data is received.

To prevent this issue, select Transmission/Reception work mode when using Smart Configurator. Use “R\_<Configuration Name>\_Serial\_Send\_Receive” function instead of “R\_<Configuration Name>\_Serial\_Receive”. The same number of data for tx\_num and rx\_num should be specified.

Disable TXDn pin in Smart Configurator Pins page and send dummy data if transmission is not required.

There will be warnings when TXDn pin is disabled. These warnings can be ignored as TXDn pin is not intended to be used originally.




Figure 6-2 Ignore warnings when TXDn pin is disabled (Example with TXD0)

### 6.2.3 Note on using high transfer speed in SCIF Synchronous Mode

If the number of reception data specified for the API ( R\_<Configuration Name>\_Serial\_Receive or R\_<Configuration Name>\_Serial\_Send\_Receive ) and reception FIFO threshold specified on GUI do not satisfy the formula below:

$$(\text{Reception Data Size}) = n * (\text{Reception FIFO threshold}) \quad (n=1,2,3,\dots)$$

extra clock generation may occur after the desired number of data is received in high communication speed when using internal clock.

To prevent this issue, specify the reception data size and reception FIFO threshold that satisfy the formula.

### 6.2.4 Note on device change functionality

Save project settings before performing change device operation. After change device, perform these operations:

1. Visual check on Components window and Configuration Problems window. Resolve errors and conflicts if there is any.
2. Check each component and convert settings.
3. Re-generate codes.

### 6.2.5 Note on using Smart Configurator for GCC project in e<sup>2</sup> studio 7.4.0

When using default options to create new "GCC for Renesas RX Executable Project" with Smart Configurator in e<sup>2</sup> studio 7.4.0, build error occurs.

```
C:\example\src\smc_gen\r_bsp\mcu/all/r_bsp_common.h:55:24:
fatal error: stdbool.h: No such file or directory
```

As workaround, use e<sup>2</sup> studio 7.5.0 to create new "GCC for Renesas RX Executable Project" with Smart Configurator.

### 6.2.6 Note on using Data Transfer Controller

Smart Configurator does not support sequence transfer, write-back skip, write-skip disable and displacement addition features.

### 6.2.7 Note on Ports setting when using S12AD components

Some pins cannot be configured as output pins when S12AD components (Single Scan Mode, Continuous Scan Mode and Group Scan Mode) are used. For more information, refer to User's Manual: Hardware of the affected groups, "12-Bit A/D Converter" chapter, "Pin Setting When Using the 12-bit A/D Converter" usage note. From SC for RX 2.4.0, this note has been highlighted on the top GUI of S12AD components.

| Device groups                                      | Port pins   |
|--|---|
| RX110, RX113                                       | P40 to P44, P46   |
| RX113  | P40 to P44, P46<br>P90 to P92   |
| RX130, RX140, RX23W, RX260,<br>RX261               | P40 to P47  |
| RX64M, RX651, RX65N, RX66N,<br>RX71M, RX72M, RX72N | P00 to P02, P03, P05, P07<br>P40 to P47<br>P90 to P93<br>PD0 to PD7<br>PE0 to PE7 |
| RX671  | P00 to P02, P03, P05, P07<br>P40 to P47<br>P90<br>PD0 to PD7<br>PE0, PE1          |

### 6.2.8 Note on section build warning when using FIT components

When using FIT components (e.g. r\_ether\_rx) with section settings, these section settings will be added automatically into IDE C/C++ builder setting, but these section settings will not automatically removed from the C/C++ builder setting when these FIT components are deleted from SC, thus there are build warnings for not finding section declaration when execute build operation after these FIT components are removed, please ignore these build warnings.



### 6.2.9 Note on C++ project support in CS+

When using Smart Configurator for C++ project application in CS+, please be noted to manually prepare the following content in the main.cpp generated out by these IDEs to make it work properly with Smart Configurator source codes.

- CS+: please manually add the following highlighted one line of code into main.cpp

```
#ifdef __cplusplus
// #include <ios> // Remove the comment when you use ios
// _SINT ios_base::init::init_cnt; // Remove the comment when you use ios
#endif

void main(void);
#ifdef __cplusplus
extern "C" {
#include "r_smc_entry.h"
void abort(void);
}
#endif

void main(void)
{
}

#ifdef __cplusplus
void abort(void)
{
}
#endif
```

### 6.2.10 Note on Installation directory

When installing Smart Configurator, you may get an error message "The specified path is too long" if the installation file path is longer than the maximum length permitted by Windows. The suggested way is to re-install the CS+ into its default path (C:\Program Files (x86)\Renesas Electronics\ or a folder whose paths' length is less than 65 characters, then install Smart Configurator again.

### 6.2.11 Note on the build error of existing RTOS C++ project

When building existing RTOS C++ CCRX project (FreeRTOS & Azure RTOS) in e<sup>2</sup> studio, there will be a build error saying "E0562310: Undefined external symbol "\_abort" referenced in "error"" in the output console, these existing projects were created by Smart Configurator for RX V2.12.0 and before version while BSP version was updated to V7.00. To resolve this build error, please add the "abort" function manually into main program file.

e.g. Add the "abort" function for FreeRTOS C++ CCRX project

```
#include "FreeRTOS.h"
#include "task.h"

void main_task(void *pvParameters)
{
    /* Create all other application tasks here */

    while(1);

    vTaskDelete(NULL);
}

void abort (void)
{
}
```

### 6.2.12 Note on the output of high impedance issue for TXDn pin

When using the serial components, the SCR.TE bit is set to 1 after changing the pin function to TXDn which will cause the output of TXDn pin becomes high impedance. To fix this issue, SCI/SCIF Asynchronous Mode component has followed the UM suggestion (set the TE bit to 1 before changing the pin function to "TXDn". Change the pin function to "general-purpose I/O port, output" before setting the TE bit to 0) and updated the generated codes from Smart Configurator for RX V2.14.0. For the other serial components as below, the generated codes are not updated to follow the UM suggestion because the high impedance time is quite short, there is no impact to these modes' communications.

- SCI/SCIF Clock Synchronous Mode
- Smart Card Interface Mode
- SPI Clock Synchronous Mode (SCI channels)

### 6.2.13 Note on the include path update issue when renaming the component's configuration name

When renaming the added component's configuration in e² studio Smart Configurator project that has self-defined include path setting for any folder or file, include path setting for that folder or file will keep the old name setting after code generation. This will cause build error when compiling the newly generated codes so please manually update the include path.

The folder or file which has self-defined include path setting can be recognized by checking the overlay icon (📁) on that folder or file. Below is an example on how to handle the include path update after renaming Compare Match Timer component configuration.




Figure 6-3 Compare Match Timer component configuration before renaming




Figure 6-4 The Compare Match Timer component configuration after renaming




Figure 6-5 Include path setting for the "Config\_S12AD0" configuration

### 6.2.14 Note on accessing “Release Notes” and “Tool News” URL from the help menu

For Smart Configurator for RX V2.15.0 or before version, “Release Notes” and “Tools News” in the help menu cannot access the correct URL. This issue has been fixed from this version.

Please access the URL below directly for Smart Configurator for RX V2.15.0 or before version.

Release Notes: <https://www.renesas.com/rx-smart-configurator-release-note>

Tool News: <https://www.renesas.com/rx-smart-configurator-tn-notes>




Figure 6-6 "Release Notes" and "Tool News" in help menu

### 6.2.15 Note on the IPCF file naming change for IAR project

From Smart Configurator for RX V2.15.0 onwards, IPCF file name has been updated from “projectname.ipcf” to “buildinfo.ipcf”, thus for existing IAR project which is using “projectname.ipcf”, please register the new IPCF file “buildinfo.ipcf” file into IAR EWRX workbench via the “Add project connection” menu to restore the connection between Smart Configurator and IAR EWRX workbench, otherwise there is no update for the generated files in the IAR EWRX workbench when changing GUI setting in Smart Configurator and then generating codes.

### 6.2.16 Note on using user code protection feature

From Smart Configurator for RX V2.16.0 onwards, user code protection feature will be supported for all Code Generation components. Please use the following specific tags to add user code when using the user code protection feature. If the specific tags do not match exactly, inserted user code will not be protected after the code generation.

```
/* Start user code */
```

**User code can be added between the specific tags**

```
/* End user code */
```

The user code protection feature will only be supported on the files that are generated by the Code Generation component. Hence, the user code protection feature is not available for non-Code Generation components.

**6.2.17 Note on code generation difference at Components tab and not at Components tab**

When using the components on the devices mentioned in following table, code generation might be different at Components tab and not at Components tab after reloading Smart Configurator project.

| Affected components                          | Affected devices   |
|--|--|
| Clock Frequency Accuracy Measurement Circuit | RX64M, RX130, RX140, RX231, RX23EB, RX651, RX71M   |
| Complementary PWM Mode                       | RX64M, RX130, RX231, RX113, RX111, RX651, RX71M  |
| Continuous Scan Mode DSAD                    | RX23E-B  |
| Normal Mode Timer                            | MTU: RX64M, RX130, RX113, RX111, RX110, RX231, RX651, RX71M<br>TPU: RX64M, RX231, RX651, RX71M |
| PWM Mode Timer                               | MTU: RX64M, RX130, RX651<br>TPU: RX64M, RX651  |
| SPI Clock Synchronous Mode (3-wire method)   | SCI: RX651, RX64M, RX130<br>RSPI: RX651, RX64M, RX130  |
| SPI Operation Mode (4-wire method)           | RX651, RX64M, RX130  |
| Single Scan Mode DSAD                        | RX23E-B  |

|                                |                                |
|--------------------------------|--------------------------------|
| MTU0.TGRA = _04E1 TGRA0_VALUE; | MTU0.TGRA = _09C3 TGRA0_VALUE; |
| MTU0.TGRB = _007C TGRB0_VALUE; | MTU0.TGRB = _00F9 TGRB0_VALUE; |
| MTU0.TGRC = _007C TGRC0_VALUE; | MTU0.TGRC = _00F9 TGRC0_VALUE; |
| MTU0.TGRD = _007C TGRD0_VALUE; | MTU0.TGRD = _00F9 TGRD0_VALUE; |
| MTU0.TGRE = _007C TGRE0_VALUE; | MTU0.TGRE = _00F9 TGRE0_VALUE; |
| MTU0.TGRF = _007C TGRF0_VALUE; | MTU0.TGRF = _00F9 TGRF0_VALUE; |

**Figure 6-7 Code generation is different at Component tab and not at Component tab**

To solve this code difference issue, please go to Components tab and open all the existing GUI of affected components and click Generate Code button.

### Revision History

| Rev. | Section | Description          |
|------|---------|----------------------|
| 1.00 | -       | First edition issued |

# General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

## 1. Precaution against Electrostatic Discharge (ESD)

A strong electrical field, when exposed to a CMOS device, can cause destruction of the gate oxide and ultimately degrade the device operation. Steps must be taken to stop the generation of static electricity as much as possible, and quickly dissipate it when it occurs. Environmental control must be adequate. When it is dry, a humidifier should be used. This is recommended to avoid using insulators that can easily build up static electricity.

Semiconductor devices must be stored and transported in an anti-static container, static shielding bag or conductive material. All test and measurement tools including work benches and floors must be grounded. The operator must also be grounded using a wrist strap. Semiconductor devices must not be touched with bare hands. Similar precautions must be taken for printed circuit boards with mounted semiconductor devices.

## 2. Processing at power-on

The state of the product is undefined at the time when power is supplied. The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the time when power is supplied. In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the time when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the time when power is supplied until the power reaches the level at which resetting is specified.

## 3. Input of signal during power-off state

Do not input signals or an I/O pull-up power supply while the device is powered off. The current injection that results from input of such a signal or I/O pull-up power supply may cause malfunction and the abnormal current that passes in the device at this time may cause degradation of internal elements. Follow the guideline for input signal during power-off state as described in your product documentation.

## 4. Handling of unused pins

Handle unused pins in accordance with the directions given under handling of unused pins in the manual. The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of the LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible.

## 5. Clock signals

After applying a reset, only release the reset line after the operating clock signal becomes stable. When switching the clock signal during program execution, wait until the target clock signal is stabilized. When the clock signal is generated with an external resonator or from an external oscillator during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Additionally, when switching to a clock signal produced with an external resonator or by an external oscillator while program execution is in progress, wait until the target clock signal is stable.

## 6. Voltage application waveform at input pin

Waveform distortion due to input noise or a reflected wave may cause malfunction. If the input of the CMOS device stays in the area between  $V_{IL}$  (Max.) and  $V_{IH}$  (Min.) due to noise, for example, the device may malfunction. Take care to prevent chattering noise from entering the device when the input level is fixed, and also in the transition period when the input level passes through the area between  $V_{IL}$  (Max.) and  $V_{IH}$  (Min.).

## 7. Prohibition of access to reserved addresses

Access to reserved addresses is prohibited. The reserved addresses are provided for possible future expansion of functions. Do not access these addresses as the correct operation of the LSI is not guaranteed.

## 8. Differences between products

Before changing from one product to another, for example to a product with a different part number, confirm that the change will not lead to problems. The characteristics of a microprocessing unit or microcontroller unit products in the same group but having a different part number might differ in terms of internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.



## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating Renesas Electronics products, if required.
5. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
6. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.
  - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.
  - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.
7. No semiconductor product is absolutely secure. Notwithstanding any security measures or features that may be implemented in Renesas Electronics hardware or software products, Renesas Electronics shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a Renesas Electronics product or a system that uses a Renesas Electronics product. RENESAS ELECTRONICS DOES NOT WARRANT OR GUARANTEE THAT RENESAS ELECTRONICS PRODUCTS, OR ANY SYSTEMS CREATED USING RENESAS ELECTRONICS PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). RENESAS ELECTRONICS DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, RENESAS ELECTRONICS DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.
8. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
12. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
13. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
14. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.5.0-1 October 2020)

## Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,  
Koto-ku, Tokyo 135-0061, Japan

[www.renesas.com](http://www.renesas.com)

## Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

## Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:

[www.renesas.com/contact/](http://www.renesas.com/contact/).