

8V79S680

QREF-to-QCLK Phase Deterministic

Abstract

This document provides the procedure to obtain a result of S680 output QREF-to-QCLK phase deterministic. To achieve phase deterministic, the source to 8V79S680 REF and CLK input should also be phase deterministic. In the procedure, the 8V19N490 QCLK and QREF outputs are used as signal source for the 8V79S680 inputs.

This document also provides general hardware interface, register data loading, and control procedure sequences on both the 8V19N490 and 8V79S680. An example experiment result is also shown in this document. The 8V79S680 QREF-to-QCLK phase deterministic only works for QCLK divider = 1.

Contents

1.	Harc	dware Interface							
2.	Procedure								
3.	Expe	eriment	3						
	3.1	8V19N490	3						
	3.2	8V79SS680	4						
	3.3	Experiment Example Result	4						
4.	Con	clusion	5						
5.	Revi	ision History	5						

Figures

Figure 1. 8V19N490 to 8V79S680 Interface	2
Figure 2. 8V19N490 Configuration	3
Figure 3. 8V79S680 Configuration	4
Figure 4. Waveform Sysref Limit Pulse Mode with Pulse Count = 4	4
Figure 5. Zoom-In to Show 8V79S680 QREF-to-QCLK Phase Deterministic	5

1. Hardware Interface

The hardware Interface between the 8V19N490 QCLK and QREF outputs to the 8V79S680 CLK and REF inputs is shown in Figure 1. The 8V19N490 QCLK to 8V79S680 CLK input can be either AC coupling or DC coupling. The 8V19N490 QCLK can be configured to either LVPECL or LVDS style driver. For the 8V19N490 QREF output to 8V79S680 REF input interface, because the timing of the first rising edge of the 8V19N490 QREF is critical, the 8V19N490 QREF to 8V79S680 REF input must be DC coupling to avoid initial AC coupling ramp-up that causes timing uncertainty. The 8V19N490 QREF DC coupling can be either an LVDS or LVPECL style driver. **Note:** If the 8V19N490 output is set to the LVDS style driver, the Bias_Type must be set to logic high/low when the QREF output is not active, such as Bias_Type = 0.



Figure 1. 8V19N490 to 8V79S680 Interface

2. Procedure

- 1. Power up the 8V19N490 and 8V79S680.
- 2. Load the 8V19N490 data to initialize and activate QCLK, but do not activate N490 Sysref.

The data contains general settings of input/output frequency, charge pump current, desired Sysref global delay, individual delay, and other system requirement configuration.

- a. Make sure the Sysref Global Power is powered up (for example, PD_S = 0, R18 D7 = 0), and the active output of the individual QREFs are powered up (PD_QREFx = 0) and enabled (EN_QREFx = 1). Make sure Sysref Pulse R70, D7 = 0 to ensure the Sysref is not activated at this point.
- b. Sysref can be in either continuous mode or limit pulse mode. (The example in this lab used limit pulse mode with pulse count = 4).
- c. Sysref can be either an internal trigger or external trigger. (The example in the following lab section used internal trigger).
- 3. Initialize the 8V19N490.
 - a. RELOCK = 1, R72, D7 = 1
 - b. PB_CAL = 1, R73, D7 = 1
 - c. INIT_CLK = 1, R71. D7 = 1
 - d. QREF is not activated at this point.
- Load the 8V79S680 data and initialize the device. At this point, the 8V79S680 QCLK output should be active. The 8V79S680 QREF is not active at this point but its REF input is ready to receive Sysref from the 8V19N490 QREF.
 - a. Load the 8V79S680 data with the desire QCLK output divider and QCLK delay.

The active QREFs are enabled; however, the signal is not active.

b. PB_CAL = 1, R73, D7 = 1



- c. RELOCK = 1, R72, D7 = 1
- d. INIT_CLK = 1, R71, D7 = 1
- 5. Activate 8V19N490 Sysref output.
 - e. At the 8V19N490, write R70, D7 = 1. Both the 8V19N490 QREF and 8V79S680 REF should be active at this point. Observe the phase delay between 8V79S680 QREF first rising edge and its QCLK rising edge.
- 6. To observe the 8V79S680 QREF to QCLK phase deterministic, turn off the power and repeat Step 1 through Step 5. The 8V79S680 QREF to QCLK should be phase deterministic.

3. Experiment

The experiment results show the 8V79S680 QCLK-to-QREF phase deterministic. The 8V19N490 QREF to 8V79S680 is also phase deterministic. The following is the set-up condition for this experiment example.

3.1 8V19N490

- Limit pulse mode with pulse count = 4
- Internal trigger
- QCLK frequency = 491.52MHz, LVDS, AC coupling
- QREF (Sysref frequency) = 7.68MHz, LVDS, Bias_Type = 0, R19, D7 = 0, DC coupling
- Sysref global delay = 1.017ns
- Individual QREF Coarse delay = 0ps
- Individual QREF Fine delay = 0ps



Figure 2. 8V19N490 Configuration



3.2 8V79SS680

- · QCLK LVDS style
- QCLK frequency divider = 1
- QCLK phase delay setting = 31 (example only, user can adjust)
- QREF LVDS with Bias_Type = 0, R19, D7 = 0
- DLC = 01
- P_DCB = 100
- M_DCB = 100

IDT8V795580 Rev C Configuration & Status Version 1.00.02 SPI 3 - wir PLL Settings, Dividers, Phase, & Status	e Data source DeVaSys Star Output Configuration	ting (Hex) 00 Number of 128	Write Registers Read Registers	Read from File Data to File?
Channels A Channel Power Divider Active //1 31 Phase 1 0 50 100 150 200 255	B Channel Power Active 31 Phase 0 50 100 150 200 250	C Channel Power Divider Channel Power Divider 1 31 Phase	D Channel Power Divider Power Divider 7 /1 9 31 Phase 0 50 100 150 200 225	General Control
SysRef Control SysRef Active SysREF Output DC DLC 01	A 100 P_DCB Ran 0 20 40 60 80 100 100 M-DCB Ran Ran	Status ge 0 to 127 127 ge 0 to 511 511 Status Status PBIAS_CODE 39 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9		

Figure 3. 8V79S680 Configuration

3.3 Experiment Example Result

- Ch2 = N490 QREF output
- Ch1 = N490 QCLK output
- Ch4 = S680 QREF output
- Ch3 = S680 QCLK output

r	le Edi	Vertical	Horiz/Acq	Trig Display	Cursors	Measure Ma	ssk Math	MyScope /	Analyze	Utilities	Help	•					Tek		X
								ر کر کار ا											
									-	0	- 14	-	-						
				_				I.											
2	State Lines										ALC: NO.								
	-	de la colora de	the state of a state			han bin di in		land it.	d				D. Deset		101/00-	. Har		100,000,00	-
0	≥``							11 ± 1		18									
	-				diamet along	or an inclusion in an		-					Sector					-	-
								Ŧ		-	1 /		~ ^*						
								· · ‡]											
														-					
		and property.		social de la Jas des s	-	and a star	en la constante	transmitter i	-		- migar		diama a	(an energy)		a an shi		and the second	
d																			
C	Tentr		and all states of all and	and the second state	and a second state	a dia Mandalan	- Contractor and	رق أنسط	and looks	-	(in the second sec	Shadle.	ل ساليون ا	Nevel at	- COL	the local data	a trained a	-	di tata
							1			4.1		-	1.1		_	_			لعد
	C1	400mV/div	v 5	0Ω ¶ _W :2.5G		-4.0ns				A' 🧲	 - - - - - -	99V		[*	00ns/di	v 10.0	GS/s IT	12.5pt	/pt
	C2	600mV/div	v 5	0Ω ¶w2.5G	- 13	130ns									review		Single S	eq Di .cco	
	CA	500mV €	offset:238m	V 50Ω Βώ-2	.56	7.463MH	-							,	luto A	pril 13.	2020	16:	16:59
																			_
			Value	Mean	Min	Max	St Dev	Count	Info										
	C2	Freq	7.678MHz	7.6780064M	7.678M	7.678M	0.0	1.0	ŏ										
	C2	Rise	138.0ps	138.0p	138.0p	138.0p	0.0	1.0	0										
	C2	Fall	152.1ps	152.06349p	152.1p	152.1p	0.0	1.0	<u> </u>										
T.	62	Ampl.	00e.0mV	309193997m	30410m	504.0m	0.0	1.0	<u> </u>										

Figure 4. Waveform Sysref Limit Pulse Mode with Pulse Count = 4





Figure 5. Zoom-In to Show 8V79S680 QREF-to-QCLK Phase Deterministic

Figure 5 is zoomed in to show the 8V79S680 QREF-to-QCLK phase deterministic as the vertical cursor marking every power-up and repeat the above steps. The 8V19N490 QREF to 8V79S680 also phase deterministic.

4. Conclusion

The 8V79S680 QREF to QCLK can be phase deterministic with proper care. The REF and CLK input must be from a phase deterministic source such as the 8V19N490 QCLK and QREF outputs. The 8V19N490 QREF output to 8V79S680 REF input interface mask is DC coupling and is set to proper Bias_Type when configured to LVDS. The 8V19N490 QCLK output to 8V79S680 CLK input interface is either DC or AC coupling. The experiment results show the phase deterministic at every power-up and followed the procedure.

5. Revision History

Revision Date	Description of Change						
Oct.28.20	Initial release.						



IMPORTANT NOTICE AND DISCLAIMER

RENESAS ELECTRONICS CORPORATION AND ITS SUBSIDIARIES ("RENESAS") PROVIDES TECHNICAL SPECIFICATIONS AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT OF THIRD-PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for developers who are designing with Renesas products. You are solely responsible for (1) selecting the appropriate products for your application, (2) designing, validating, and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. Renesas grants you permission to use these resources only to develop an application that uses Renesas products. Other reproduction or use of these resources is strictly prohibited. No license is granted to any other Renesas intellectual property or to any third-party intellectual property. Renesas disclaims responsibility for, and you will fully indemnify Renesas and its representatives against, any claims, damages, costs, losses, or liabilities arising from your use of these resources. Renesas' products are provided only subject to Renesas' Terms and Conditions of Sale or other applicable terms agreed to in writing. No use of any Renesas resources expands or otherwise alters any applicable warranties or warranty disclaimers for these products.

(Disclaimer Rev.1.01)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan www.renesas.com

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

Contact Information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit <u>www.renesas.com/contact-us/</u>.