

## Precautions on Using Flash Development Toolkit

READ this document before using .this toolkit  
KEEP the document handy for future reference.

### 1. The action when the FDT sends "Timeout error"

(1) When you use the FDT with the following conditions, you may get "Timeout error"

- Using low performance and small RAM PC
- Using upload function
- Using verify function after programming the flash data
- At the beginning of adjustment of baud rate

Please change baud rate to lower rate, when you get this error.

(2) When you get a message "ERROR : Error while reading timed response"  
at the connection to a device, please change baud rate to lower rate.

### 2. Setting of Project Properties

When you change baud rate, frequency or other values, please close the project properties window. Closing the window makes changed values effective.

### 3. Selection of 1200bps communication

FDT supports only H8/38024F device with 1200bps communication speed.

Please don't select 1200bps communication speed with other devices.

### 4. Connection with an adapter board(Flash Development Module)

When a target device is a USB boot product (e.g. H8S/2215UF), connection with an adapter board(Flash Development Module) cannot be performed.