

Application Note DA9213 Standard Variants Overview

AN-PM-121

Abstract

This application note describes the default register settings of the DA9213 standard variants.



DA9213 Standard Variants Overview

Contents

Ab	stract	1
Co	ntents	2
Fig	jures	2
Та	bles	2
1	Terms and Definitions	3
2	References	3
3	Introduction	4
	3.1 System Diagram	4
	3.2 Variant Table and Ordering Information	4
4	DA9213-JEUP Detailed Description	5
5	DA9213-88UP Detailed Description	7
6	DA9213 Standard Variants Overview	9
7	Conclusions 1	0
Re	vision History1	1

Figures

Figure T. DA9213 System Diagram

Tables

Table 1: Ordering Information	4
Table 2: DA9213-JEUP Register Settings	5
Table 3: DA9213-88UP Register Settings	7
Table 4: DA9213 Standard Variants Overview	9



1 Terms and Definitions

CPU	Central Processing Unit
GPIO	General Purpose Input/Output
GPU	Graphic Processing Unit
OTP	One Time Programmable (Memory)
PMU	Power Management Unit
PWM	Pulse-Width Modulation

2 References

[1] DA9213, Datasheet, Dialog Semiconductor.



3 Introduction

The DA9213 is a PMU optimized for the supply of CPUs, GPUs, and DDR memory rails in smartphones, tablets and other portable applications. The fast transient response and load regulation are optimized for the latest generation of multi-core application processors. The DA9213 operates as a single four-phase buck converter delivering up to 20 A output current.

This application note intended to help a hardware designer understand the configurations of the DA9213 standard variants.



3.1 System Diagram



3.2 Variant Table and Ordering Information

Table 1: Ordering Information

Part Number	Package	Shipment Form	Pack Quantity
DA9213-xxUP2	66 WL-CSP	Tape and Reel	4500pcs
DA9213-xxUP6	66 WL-CSP	Waffle	
DA9213-JEUP2	66 WL-CSP	Tape and Reel	4500pcs
DA9213-JEUP6	66 WL-CSP	Tray	
DA9213-88UP2	66 WL-CSP	Tape and Reel	4500pcs
DA9213-88UP2	66 WL-CSP	Waffle	



4 DA9213-JEUP Detailed Description

Key settings:

- Default output voltage is set to 1.0 V.
- Buck is set to operate in SYNC (forced PWM) mode.
- Maximum allowed output voltage is set to 1.57 V.
- GPI0, GPI1, GPIO2, GPIO3 and GPI4 are assigned as active-high digital input.

Table 2: DA9213-JEUP Register Settings

Register Address	Function	Default Value	Description
0x054	MASK_A	0x5F	nIRQ interrupt at GPI0 to GPI4 and UVLO_IO caused nIRQ are masked.
0x055	MASK_B	0x3F	PWRGOOD Buck A and Buck B, TEMP_WARN, TEMP_CRIT, OV_CURR Buck A and OV_CURR Buck B caused event are masked.
0x056	CONTROL_A	0x53	GPIO debounce time = 10 ms DVC slew rate A = 10 mV/ μ s DVC slew rate B = 10 mV/ μ s V_LOCK = 0: Allows host writes into registers 0xD0 to 0x14F.
0x058	GPI0-1	0x44	GPI0: input, active high, debouncing off. GPI1: input, active high, debouncing off.
0x059	GPIO2-3	0x44	GPIO2: input, active high, debouncing off. GPIO3: input, active high, debouncing off.
0x05A	GPI4	0x04	GPI4: input, active high, debouncing off.
0x05D	BUCKA_CONT	0x00	Buck is default OFF. Pull down resistor is enabled. Buck output voltage is selected from VBUCK_A.
0x0D0	BUCK_ILIM	0x99	Current limit per phase BUCKA_ILIM = 5800 mA (peak inductor current)
0x0D1	BUCKA_CONF	0x92	Operation mode is set to SYNC (forced PWM) mode. Start-up control = 20 mV/µs Down control = 20 mV/µs
0x0D3	VBUCK_CONF	0x1F	Maximum 4-phase is selected. Phase-shedding is enabled.
0x0D5	VBUCKA_MAX	0x7F	Max output voltage VBUCKA_MAX = 1.57 V
0x0D7	VBUCKA_A	0x46	Output voltage VBUCKA_A = 1.00 V
0x0D8	VBUCKA_B	0x46	Output voltage VBUCKA_B = 1.00 V
0x105	INTERFACE	0xD9	Primary 2-wire interface slave address = 0xD0
0x106	INTERFACE2	0x80	Communication interface is 2-wire, standard speed, PM_IF_V=VDDCORE.
0x143	CONFIG_A	0x12	Enabled automatic reset of 2-WIRE interface in case of clock stays low for >35 ms.
			nIRQ output port is open drain, active low. GPIs are supplied from VDDCORE.
0x144	CONFIG_B	0xE0	UVLO_IO is disabled. Power good signal masked during DVC transitions (keep previous status). Reload function is disabled.

Application Note



DA9213 Standard Variants Overview

Register Address	Function	Default Value	Description
0x145	CONFIG_C	0x00	GPI0, GPI1, GPIO2, GPIO3 and GPI4 pull-down resistors are disabled.
0x146	CONFIG_D	0x00	Buck Power Good (PG) and READY are not assigned to any GPIOs.
0x147	CONFIG_E	0x80	DA9213 is set as standalone device. No tune of oscillator frequency.
0x148	CONFIG_F	0xD0	Secondary 2-wire interface slave address = 0xD0

5 DA9213-88UP Detailed Description

Key settings:

- Default output voltage is set to 0.85 V.
- Secondary voltage is set to 0.90 V and can be triggered via GPIO1.
- Buck is set to operate in AUTO mode.
- Maximum allowed output voltage is set to 1.57 V.
- GPI0 is assigned as active-high digital input and serves as buck enable/disable pin.
- GPI1 is assigned as active- high digital input and serves as buck output voltage switch pin.
- GPIO2 is assigned active-high open-drain output and serves as a ready signal output pin.
- GPIO3 is assigned as active-high open-drain output and serves as a power good signal output pin
- GPI4 is not used.

Table 3: DA9213-88UP Register Settings

Register Address	Function	Default Value	Description
0x054	MASK_A	0x5F	nIRQ interrupt at GPI0 to GPI4 and UVLO_IO caused nIRQ are masked.
0x055	MASK_B	0x3F	PWRGOOD Buck A and Buck B, TEMP_WARN, TEMP_CRIT, OV_CURR Buck A and OV_CURR Buck B caused event are masked.
0x056	CONTROL_A	0x51	GPIO debounce time = 0.1 ms DVC slew rate A = 10 mV/ μ s DVC slew rate B = 10 mV/ μ s V_LOCK = 0: Allows host writes into registers 0xD0 to 0x14F.
0x058	GPI0-1	0x44	GPI0: input, active high, debouncing off. GPI1: input, active high, debouncing off.
0x059	GPIO2-3	0xEE	GPIO2: output open-drain, active high, debouncing on. GPIO3: output open-drain, active high, debouncing on.
0x05A	GPI4	0x0C	GPI4: input, active high, debouncing on.
0x05D	BUCKA_CONT	0x22	Buck is default OFF. Pull down resistor is enabled. Buck is controlled by GPI0 (enable on passive to active, disable on active to passive). VBUCK is controlled by GPI1 (VBUCK_A on active to passive, VBUCK_B on passive to active).
0x0D0	BUCK_ILIM	0xFF	Current limit per phase BUCKA_ILIM = 7000 mA. (peak inductor current)
0x0D1	BUCKA_CONF	0x0F	Operation mode is set to AUTO mode. Start-up control = 10 mV/µs Down control = 1.25 mV/µs
0x0D3	VBUCK_CONF	0x1F	Maximum 4-phase is selected. Phase-shedding is enabled.
0x0D5	VBUCKA_MAX	0x7F	Max output voltage VBUCKA_MAX = 1.57 V
0x0D7	VBUCKA_A	0x37	Output voltage VBUCKA_A = 0.85 V
0x0D8	VBUCKA_B	0x3C	Output voltage VBUCKA_B = 0.9 V
0x105	INTERFACE	0xD9	Primary 2-wire interface slave address = 0xD0
0x106	INTERFACE2	0x90	Communication interface is 2-wire, standard speed,

Application Note

24-Feb-2022



DA9213 Standard Variants Overview

Register Address	Function	Default Value	Description
			PM_IF_V=VDDIO.
0x143	CONFIG_A	0x1A	Enabled automatic reset of 2-WIRE interface in case of clock stays low for > 35 ms.
			nIRQ output port is open drain, active low. GPIs are supplied from VDDIO.
0x144	CONFIG_B	0xE0	UVLO_IO is disabled. Power good signal masked during DVC transitions (keep previous status). Reload function is disabled.
0x145	CONFIG_C	0x1F	GPI0, GPI1, and GPI4 pull-down resistors are enabled. GPO2 and GPO3 pull-up resistors are enabled.
0x146	CONFIG_D	0x21	GPO3 is assigned as Power Good (PG), GPO2 is assigned as READY.
0x147	CONFIG_E	0x80	DA9213 is set as standalone device. No tune of oscillator frequency.
0x148	CONFIG_F	0xD0	Secondary 2-wire interface slave address = 0xD0

8 of 12



6 DA9213 Standard Variants Overview

Table 4: DA9213 Standard Variants Overview

Register	Function	Standard Variant DA9213-				
Address		JEUP	88UP			
0x054	MASK_A	0x5F	0x5F			
0x055	MASK_B	0x3F	0x3F			
0x056	CONTROL_A	0x53	0x51			
0x058	GPI0-1	0x44	0x44			
0x059	GPIO2-3	0x44	0xEE			
0x05A	GPI4	0x04	0x0C			
0x05D	BUCKA_CONT	0x00	0x22			
0x0D0	BUCK_ILIM	0x99	0xFF			
0x0D1	BUCKA_CONF	0x92	0x0F			
0x0D3	VBUCK_CONF	0x1F	0x1F			
0x0D5	VBUCKA_MAX	0x7F	0x7F			
0x0D7	VBUCKA_A	0x46	0x37			
0x0D8	VBUCKA_B	0x46	0x3C			
0x105	INTERFACE	0xD9	0xD9			
0x106	INTERFACE2	0x80	0x90			
0x143	CONFIG_A	0x12	0x1A			
0x144	CONFIG_B	0xE0	0xE0			
0x145	CONFIG_C	0x00	0x1F			
0x146	CONFIG_D	0x00	0x21			
0x147	CONFIG_E	0x80	0x80			
0x148	CONFIG_F	0xD0	0xD0			

9 of 12



7 Conclusions

Understanding the configuration of the OTP described in this document can help minimize system issues such as incorrect hardware configuration. For further information please refer to the datasheets [1], on the Dialog website (https://www.dialog-semiconductor.com/pmics) or contact Dialog via either your sales representative or the support forum (https://support.dialog-semiconductor.com/forums/pmic-audio).

Application Note



DA9213 Standard Variants Overview

Revision History

Revision	Date	Description
1.0	06-Aug-2018	Initial version.
1.1	24-Feb-2022	File was rebranded with new logo, copyright and disclaimer





Status Definitions

Status	Definition
DRAFT	The content of this document is under review and subject to formal approval, which may result in modifications or additions.
APPROVED or unmarked	The content of this document has been approved for publication.

RoHS Compliance

Dialog Semiconductor's suppliers certify that its products are in compliance with the requirements of Directive 2011/65/EU of the European Parliament on the restriction of the use of certain hazardous substances in electrical and electronic equipment. RoHS certificates from our suppliers are available on request.

IMPORTANT NOTICE AND DISCLAIMER

RENESAS ELECTRONICS CORPORATION AND ITS SUBSIDIARIES ("RENESAS") PROVIDES TECHNICAL SPECIFICATIONS AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT OF THIRD-PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for developers who are designing with Renesas products. You are solely responsible for (1) selecting the appropriate products for your application, (2) designing, validating, and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. Renesas grants you permission to use these resources only to develop an application that uses Renesas products. Other reproduction or use of these resources is strictly prohibited. No license is granted to any other Renesas intellectual property or to any third-party intellectual property. Renesas disclaims responsibility for, and you will fully indemnify Renesas and its representatives against, any claims, damages, costs, losses, or liabilities arising from your use of these resources. Renesas' products are provided only subject to Renesas' Terms and Conditions of Sale or other applicable terms agreed to in writing. No use of any Renesas resources expands or otherwise alters any applicable warranties or warranty disclaimers for these products.

(Disclaimer Rev.1.01)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan www.renesas.com

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

Contact Information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit <u>www.renesas.com/contact-us/</u>.